

1. Connect the USB connector to the USB port on the PC system.
2. Connect the power connector from nodedock to the PC system.
3. Open the top cover of the mouse and insert 2 AA batteries. Take off the keyboard cover and insert 4 AAA batteries. Put back the battery doors.
4. Place mouse and keyboard in a distance of 1.5M to the nodedock. Within 10 seconds, press the synchronization button on the mouse and keyboard, then press the button on the receiver. The nodedock green LED will start blinking if the synchronization functions normally.
5. Low Voltage Indicator: Mouse is in low voltage when the blue light is blinking in the mouse. Please change the battery when the top left LED indicator is blinking red light.
6. You can dock your MP3 player into the MP3 cup on the nodedock, all other 3 USB connectors can be inserted with any USB device.
7. You can insert any 1394 connector into the 1394 connection on the nodedock, and also insert the 1394 connector into the PC system.
8. Nodedock contains 6-in-1 card reader function. It is compatible with CF card, SM card, memory stick, SD card, MMC and MicroDrive card.