

## SENDING MESSAGES

1. Press the Call Function Button to call the receiver.
2. To maximize clarity, hold radio 3 to 5 inches from mouth. Press the Push-To-Talk Button and speak into radio.
3. To receive messages, release the Push-To-Talk Button.



## LCD BACK LIGHT

Press the Back Light Button. Light stays on for 5 seconds.

## HANDS-FREE USE

1. Open accessory jack cover and plug the accessory's connector into jack.
2. Turn radio on and lower volume before placing accessory on head or in ear.
3. Rotating Volume Control to adjust volume to a comfortable listening level.
4. To transmit, speak into the accessory microphone, to receive, stop talking

## Safety Information

Your wireless handheld portable transceiver is a low power radio. When the PTT button is pushed it sends out radio frequency (RF) signals. In August 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones.

**Important:** To maintain Compliance with the FCC's RF exposure guidelines, if you wear a handset on your body use only the (DESIGN CONCEPTS) supplied carrying case, holster or other body-worn accessory for this product and ensure that the antenna is at least 1 inch (2.5 centimeters) from your body when transmitting.

Use only the supplied antenna. Unauthorized antennas, modifications, or attachments could damage the transmitter and may violate FCC regulations.

**Normal Position:** Hold the transmitter approximately 1" from your face and speak in a normal voice, with the antenna pointed up and away.

## Safety Information

The wireless hand-held portable transceiver contains a low power transmitter. When the Push-to-Talk button is pushed it sends out radio frequency (RF) signals.

The device is authorized to operate at a duty factor not to exceed 50%. In August 1996 the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless devices.

### **CAUTION :**

To maintain compliance with the FCC's RF exposure guidelines, hold the transmitter and antenna at least 1 inch (2.5 centimeters) from your face and speak in normal voice, with the antenna pointed up and away from your face.

If you wear the handset on your body while using the headset accessory, use only the manufacturers supplied belt clip for this product and ensure that the antenna is at least 1 inch (2.5 centimeters) from your body when transmitting.

Use only the supplied antenna. Unauthorized antennas, modifications, or attachments could damage the transmitter and may violate FCC regulations.