


● 9V batteries x 1 (BATTERIES NOT INCLUDED)




● Unscrew the screw before open the battery cover.

● AA-size 1.5V batteries x 4 (BATTERIES NOT INCLUDED)

### NOTE:

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

Non-rechargeable batteries are not to be recharged.  
 Different types of batteries or new and used batteries are not to be mixed.  
 Only batteries of the same or equivalent type as recommended are to be used.  
 Batteries are to be inserted with correct polarity.  
 Exhausted batteries are to be removed from the toy.  
 The supply terminals are not to be short-circuited.  
 Rechargeable batteries are to be removed from the toy before being charged.  
 Rechargeable batteries are only to be charged under adult supervision.



Color and Contents may vary from those illustrated.  
 Keep this packaging for future reference.

**WARNING:**  
 CHOKING HAZARD—Small parts.  
 Not for children under 3 years.