

## Circuit Description:

Fuse: When input is shorted, it performs input shorted protect function.

L1, C0: Work together with to performs EMI function.

D1, D2, D3, D4: Performs rectification function.

Q1, Q2, T: Performs Oscillating function, let low frequency switch high frequency.

L2, C5: When switching power, the L1 and C6 take place series resonance startup the lamp, then L1 restricting current.