

NOTES:

1.  This assembly includes components which are subject to damage by electrostatic charges. Obey all applicable ESD precautions when handling electrostatic discharge sensitive devices.
2.  Install the label (item 2) to the front plate at the approximate position shown. On the label (item 2), type the applicable part number, dash number, serial number, nominal weight of 17.10 lbs, and mark the applicable hardware/software modification letter.
3.  Install the decal (item 3) and the instruction plate (item 4). Install the product signature plate (item 5) to the front plate at the approximate position shown.
4. Refer to ATP 8007548-001 for testing instructions.

E9005000-10000-1-B




Figure 2001 (Sheet 1). T³CAS CU Assembly 6MCU, 9005000–10000, Detail
Graphic 34-09-01-991-002-A01






Figure 2001 (Sheet 3). T³CAS CU Assembly 6MCU, 9005000–10000, Detail
Graphic 34–09–01–991–002–A01

COMPONENT MAINTENANCE MANUAL – VOL II
T³CAS Traffic Management Computer / Part No. 9005000

