

USER'S MANUAL

*Energy Saving Light Bulb

*Works with Standard incandescent Dimmers, Photo Sensors and Timers

*Light Weight, Flicker Free

*Instant on Electronic Ballast

CAUTIONS

*Use only on 120volts, 60hertz frequency.

*Never disassemble or modify the bulb.

*Not for use in totally enclosed recessed fixtures.

*Risk of electric shock. Do not use where directly exposed to water.

*This device is not intended for use with emergency exit fixtures or emergency exit lights.

*This product may produce interference with a T.V., Radio or a wireless remote control. If interference should occur, move the lamp away from the appliance a distance of three feet or more.

Or, plug the lamp or the appliance into a different outlet.

This product complies with Part 18 of FCC rules.

*To prevent burns, please do not touch the bulb during operation or immediately after switching off.

*Added weight of the device may cause instability of a free-standing portable lamp. Use only with portable table lamps in which the distance from the bottom of the base to the top of the lampholder does not exceed three(3) times minimum base width .

Use only with portable table lamps which are provided with lamp shades.

*Use in sockets in recessed cans controlled by wall dimmers may shorten lamp life.