

USER MANUAL

APPLICATION

Restaurants Hotels Homes Supermarkets Offices Stores

PRECAUTIONS

1. Never use on a source voltage that fluctuates 6% above or 10% below the lamp's rated voltage.
2. Never disassemble or modify – any changes could void the user's authority to operate this device.
3. Do not hold the glass tube while installing.
4. Not for use in totally enclosed fixtures.
5. Risk of electric shock- do not use where directly exposed to water.
6. This device is not intended for use with emergency exit fixtures or emergency exit lights.
7. This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45-30MHz
8. To prevent burns, do not touch the bulb during operation or immediately after switching off.
9. Not for use with dimmers, electronic timer or photocell devices or occupancy sensor.
10. Never use in circumstance such as low or high temperature and high moisture.
11. Unsuitable for applications where the lamp must be turned on and off frequently.

The device complies with Part 18 of the FCC rules.

FEATURES

Long life Soft and brisk light Wide voltage range
1/4 Power consumption compared with standard bulb 1/4 Heat radiation compared with standard bulb