

HUNG YI ENTERPRISE CO., LTD.
1097 REMOTE CONTROL USER'S GUIDE

HOW TO ASSEMBLY :

1. MAKE SURE THE AC POWER IS 220V-240V 50/60Hz
2. SEE THE PUSH-BUTTON OF ROLLING-DOOR. (CARAGE DOOR) AND MEMEORY THE WIRE'S COLOR.
3. FOR SAFETY. TURN OFF AC POWER.
4. CONNECT THE WIRE OF RECIEVER TO PUSH-BUTTON'S WIRE.
5. CONNECT THE 2 BLACK WIRES TO POWER SOURCE.
6. INSERT THE CONNECTOR TO SOCKET OF RECEIVER.

WARNING :

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.

consult the dealer or an experienced radio/TV Technician for help.