2. Photograph of the test configuration

3. Sample Calculation

The emission level measured in decibels above one microvolt (dB) was converted into microvolt per meter (/m) as shown in following sample calculation.

For example :

Measured Value at	312.0 MHz	37.9 dB
+ Antenna Factor		14.0 dB/m
+ Cable Loss		3.3 dB
- Preamplifier		30.0 dB
- Distance Correction Factor *		0.0 dB

= Radiated Emission		25.2 dB /m
		(= 18.2 /m)

* Extrapolated from the measured distance to the specified distance by an inverse linear distance extrapolation.