


# QUICK START GUIDE


## Know the fundamentals

### ① Charge




Insert charging cable into right temple. Steady green LED light indicates charging is complete.

### ② Storage



Insert Micro SD card fully into left temple hinge until clicks into place.


### ③ Power



Press power button located inside left temple. Steady blue LED light indicates eyewear is on.


### Capturing and downloading media

### ④ Swipe




Swipe forward to start a video. Swipe forward again to stop. Flashing red LED light indicates recording.

## ⑤ Tap



Tap to capture photos. Tap twice to capture burst shots. Tap three times to start/stop a time-lapse.

## ⑥ Download



Download media from left temple with left branch of supplied cable. Suggested to supply power to right temple during media transfer.

# FCC Notice to Users

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.