

Information for NOM, or Official Mexican Standard (Only for Mexico)

The following information is provided in the device(s) described in this document in accordance with the requirements of the Official Mexican Standard (NOM):

Importer:

Dell México S.A. de C.V.  
Paseo de la Reforma 2620 – Flat 11°  
Col. Lomas Altas  
11950 México, D.F.

Regulatory model number: P29G

Input voltage: 100–240 VAC

Input current (maximum): 1.30 A

Input frequency: 50–60 Hz

Rated output current: 2.30 A

Rated output voltage: 19.50 VDC

For details, read the safety information that shipped with your computer. For additional safety best practices information, see [dell.com/regulatory\\_compliance](#).

Information in this document is subject to change without notice.

© 2011 Dell Inc. All rights reserved.

Dell™, the DELL logo, and XPS™ are trademarks of Dell Inc. Windows® is either a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.

Regulatory model: P29G | Type: P29G001

Computer model: XPS L321X

Information in this document is subject to change without notice.

© 2011 Dell Inc. All rights reserved.

Dell™, the DELL logo, and XPS™ are trademarks of Dell Inc. Windows® is either a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.

Regulatory model: P29G | Type: P29G001

Computer model: XPS L321X

Information in this document is subject to change without notice.

© 2011 Dell Inc. All rights reserved.

Dell™, the DELL logo, and XPS™ are trademarks of Dell Inc. Windows® is either a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.

Regulatory model: P29G | Type: P29G001

Computer model: XPS L321X

Information in this document is subject to change without notice.

© 2011 Dell Inc. All rights reserved.

Dell™, the DELL logo, and XPS™ are trademarks of Dell Inc. Windows® is either a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.

Regulatory model: P29G | Type: P29G001

Computer model: XPS L321X

Information in this document is subject to change without notice.

© 2011 Dell Inc. All rights reserved.

Dell™, the DELL logo, and XPS™ are trademarks of Dell Inc. Windows® is either a trademark or registered trademark of Microsoft Corporation in the United States and/or other countries.

Regulatory model: P29G | Type: P29G001

Computer model: XPS L321X

More Information

- To learn about the features and advanced options available on your laptop, click **Start** → **All Programs** → **Dell Help Documentation** or go to [support.dell.com/manuals](#).
- To contact Dell for sales, technical support, or customer service issues, go to [dell.com/ContactDell](#). Customers in the United States can call 800-WWW-DELL (800-999-3355).

More Information

- To learn about the features and advanced options available on your laptop, click **Start** → **All Programs** → **Dell Help Documentation** or go to [support.dell.com/manuals](#).
- To contact Dell for sales, technical support, or customer service issues, go to [dell.com/ContactDell](#). Customers in the United States can call 800-WWW-DELL (800-999-3355).

More Information

- To learn about the features and advanced options available on your laptop, click **Start** → **All Programs** → **Dell Help Documentation** or go to [support.dell.com/manuals](#).
- To contact Dell for sales, technical support, or customer service issues, go to [dell.com/ContactDell](#). Customers in the United States can call 800-WWW-DELL (800-999-3355).

More Information

- To learn about the features and advanced options available on your laptop, click **Start** → **All Programs** → **Dell Help Documentation** or go to [support.dell.com/manuals](#).
- To contact Dell for sales, technical support, or customer service issues, go to [dell.com/ContactDell](#). Customers in the United States can call 800-WWW-DELL (800-999-3355).


More Information

- To learn about the features and advanced options available on your laptop, click **Start** → **All Programs** → **Dell Help Documentation** or go to [support.dell.com/manuals](#).
- To contact Dell for sales, technical support, or customer service issues, go to [dell.com/ContactDell](#). Customers in the United States can call 800-WWW-DELL (800-999-3355).



Features

Features | Features | Features | Features



- Digital microphones (2)
- Camera status indicator
- Camera
- Ambient light sensor
- Display
- Power button
- AC adapter connector
- USB 2.0 connector
- Headphone/Microphone combo connector
- Left-click area
- Touchpad
- Right-click area
- Backlit keyboard
- Power indicator light
- Battery status lights
- Battery status button
- USB 3.0 connector
- Mini-DisplayPort connector

- Digital microphones (2)
- Camera status indicator
- Camera
- Ambient light sensor
- Display
- Power button
- AC adapter connector
- USB 2.0 connector
- Headphone/Microphone combo connector
- Left-click area
- Touchpad
- Right-click area
- Backlit keyboard
- Power indicator light
- Battery status lights
- Battery status button
- USB 3.0 connector
- Mini-DisplayPort connector

- Digital microphones (2)
- Camera status indicator
- Camera
- Ambient light sensor
- Display
- Power button
- AC adapter connector
- USB 2.0 connector
- Headphone/Microphone combo connector
- Left-click area
- Touchpad
- Right-click area
- Backlit keyboard
- Power indicator light
- Battery status lights
- Battery status button
- USB 3.0 connector
- Mini-DisplayPort connector

- Digital microphones (2)
- Camera status indicator
- Camera
- Ambient light sensor
- Display
- Power button
- AC adapter connector
- USB 2.0 connector
- Headphone/Microphone combo connector
- Left-click area
- Touchpad
- Right-click area
- Backlit keyboard
- Power indicator light
- Battery status lights
- Battery status button
- USB 3.0 connector
- Mini-DisplayPort connector

- Digital microphones (2)
- Camera status indicator
- Camera
- Ambient light sensor
- Display
- Power button
- AC adapter connector
- USB 2.0 connector
- Headphone/Microphone combo connector
- Left-click area
- Touchpad
- Right-click area
- Backlit keyboard
- Power indicator light
- Battery status lights
- Battery status button
- USB 3.0 connector
- Mini-DisplayPort connector

- Digital microphones (2)
- Camera status indicator
- Camera
- Ambient light sensor
- Display
- Power button
- AC adapter connector
- USB 2.0 connector
- Headphone/Microphone combo connector
- Left-click area
- Touchpad
- Right-click area
- Backlit keyboard
- Power indicator light
- Battery status lights
- Battery status button
- USB 3.0 connector
- Mini-DisplayPort connector

XPS 13

Quick Start Guide

Ugia seque eost | Ugia seque eostrumquae pero mod

Ugia seque eostrum | Ugia seque eost




Quick Start

Quick Start | Quick Start | Quick Start | Quick Start


1 Connect the AC adapter

Connect the AC adapter | Connect the AC adapter  
Connect the AC adapter | Connect the AC adapter



2 Press the power button

Press the power button | Press the power button  
Press the power button | Press the power button



3 Set up Windows

Set up Windows | Set up Windows | Set up Windows | Set up Windows



Record your Windows password here

NOTE: Do not use the @ symbol in your password

Record your Windows password here

NOTE: Do not use the @ symbol in your password

Record your Windows password here

NOTE: Do not use the @ symbol in your password

Record your Windows password here


NOTE: Do not use the @ symbol in your password

Record your Windows password here

NOTE: Do not use the @ symbol in your password

4 Check wireless status

Check wireless status | Check wireless status  
Check wireless status | Check wireless status



Function Key Behavior

Function Key Behavior | Function Key Behavior

Function Key Behavior | Function Key Behavior


Fn +		Switch to external display	Switch to external display Switch to external display Switch to external display
		Turn off/on wireless	Turn off/on wireless   Turn off/on wireless Turn off/on wireless   Turn off/on wireless
		Show battery meter	Show battery meter   Show battery meter Show battery meter   Show battery meter
		Decrease brightness	Decrease brightness   Decrease brightness Decrease brightness   Decrease brightness
		Increase brightness	Increase brightness   Increase brightness Increase brightness   Increase brightness
Fn +		Toggle keyboard backlight	Toggle keyboard backlight Toggle keyboard backlight Toggle keyboard backlight
		Play previous track or chapter	Play previous track or chapter Play previous track or chapter Play previous track or chapter
		Play/Pause	Play/Pause   Play/Pause Play/Pause   Play/Pause
		Play next track or chapter	Play next track or chapter Play next track or chapter Play next track or chapter
		Decrease volume level	Decrease volume level Decrease volume level Decrease volume level
Fn +		Increase volume level	Increase volume level Increase volume level Increase volume level

Before You Call

Before You Call | Before You Call | Before You Call | Before You Call

Locate your service tag

Locate your service tag | Locate your service tag  
Locate your service tag | Locate your service tag



Record your service tag here

Record your service tag here | Record your service tag here  
Record your service tag here | Record your service tag here