Quick Start XPS™ 12

快速入门

Regulatory  管制	
Model   型号	P20S
Type   类型	P20S001



Read the safety information that shipped with your computer. For additional safety best practices information, see the Regulatory Compliance Homepage at <a href="https://www.dell.com/regulatory\_compliance">www.dell.com/regulatory\_compliance</a>.



请阅读计算机附带的安全信息。 有关其它最佳安全操作信息,请参阅合规主页 <u>www.dell.com/regulatory\_compliance</u>。



Retain the filler brackets or cards that ship with your computer. Installing filler brackets or filler cards over empty card-slot openings is necessary to maintain FCC certification of the computer. The filler brackets and filler cards keep dust and dirt out of your computer and maintain the airflow that cools your computer.



保留计算机附带的填充托架或填充卡。 您必须在闲置的卡槽开口处安装填充托架或填充卡,才能维持本计算机的 FCC 认证。 填充托架或填充卡可以防止灰尘进入 计算机,同时保持通风以冷却计算机。


## AC Adapter | 交流适配器

Input voltage 输入电压	100-240 VAC
Input current (maximum) 输入电流(最大值)	1.30 A
Input frequency 输入频率	50 Hz - 60 Hz
Output current 输出电流	2.31 A
Output voltage 输出电压	19.5 ± 1 VDC

Notebooks and all-in-one models (No translation required for this header row)

Connect the external AC adapter.

连接外部交流适配器。



Power on the computer (and the display, if connected).

打开计算机(和显示器,如果已连接)的电源。



Depending on your computer configuration, some ports or connectors may not be available.



某些端口或连接器可能无法使用,具体取决于计算机的配置。

Icons   图标	
AC-adapter 交流适配器	===
<b>USB</b> USB	or SS
USB + PowerShare USB + PowerShare	<b>←</b>
Mini-DisplayPort 迷你 DisplayPort	#P
Headset/Audio-out 耳机/音频输出	

## Icons | 图标 Screen-rotation lock 屏幕旋转锁定/解锁