






Annex F. Photographs






F.1 Test Sample

9560 D2W Module: 170919-03.S24 (Front view)	9560 D2W Module: 170919-03.S24 (Back view)
	
Adapter: 170509-02.S02 (Front view)	Adapter: 170509-02.S02 (Back view)
	
Platform Extender: 170524-02.S14	Laptop PC Host: 170000-01.S16
	

F.2 PIFA antenna: reference test positions and general setup

Antenna Front View	Antenna Positions
General Setup	

F.3 Testing positions at 5mm

Top Edge	Bottom Edge
	
Left Edge	Right Edge
	
Front Face	Back Face
	

F.4 Phantom liquid level during measurements

ELI phantom Body liquid SAR Dasy SPEAG MBBL600-6000V6 Batch -160603-01

