

Photographs of EUT Setup and Antenna Location



The photographs of EUT and setup for SAR testing are shown as follows.

Please select antenna position and describe 'antenna location' in below picture as the right example shows.

Antenna Location
<input checked="" type="checkbox"/> Lower Position
<input type="checkbox"/> Upper Position

Lower Position (Hinge CAP)

Main(Ant0) :: WLAN Tx/ Rx ,
Aux(Ant1) : WLAN Tx/ Rx , BT Tx/Rx



<Photographs of Bottom Body SAR Test Setup>



Bottom of EUT Tested at 0 mm

<Photographs of Power Density Test Setup>

