


Annex F. Photographs

F.1 Test Sample



F.2 Test positions

Laptop



F.3 Antenna host platform location and adjacent edge positions relative to the body

All information (diagrams, values and dimensions) in this section is provided by the manufacturer

Antenna Host Platform location

Diagram illustrating the Antenna Host Platform location on a laptop. The laptop is shown in a top-down view, oriented with 'Top' at the top, 'Bottom' at the bottom, 'Left' on the left, and 'Right' on the right. The 'Display' is at the top, and the 'Keyboard' is at the bottom. Two antennas are shown: 'WLAN Main' on the left and 'WLAN Aux' on the right. Dimensions A, B, C, D, E, F, G, H, I, J, K, L, X, Y, and Z are indicated with arrows and labels. A note at the bottom states 'NB mode open 90°'.

Diagram illustrating the Antenna Host Platform location on a laptop. The laptop is shown in a top-down view, oriented with 'Top' at the top, 'Bottom' at the bottom, 'Left' on the left, and 'Right' on the right. The 'Display' is at the top, and the 'Keyboard' is at the bottom. Two antennas are shown: 'WLAN Main' on the left and 'WLAN Aux' on the right. Dimensions A, B, C, D, E, F, G, H, I, J, K, L, X, Y, and Z are indicated with arrows and labels. A note at the bottom states 'NB mode open 90°'.


Antenna Host Platform location

Minimum Separation Distance			
Item	Antenna	Position	Distance (mm)
A	WLAN-Main	To top	350
B	WLAN-Main	To left	8.83
C	WLAN-Main	To right	334.84
D	WLAN-Main	To bottom	15.7
E	WLAN-Main	Main antenna length	6.7
F	Main-Aux	Main to Aux	336
G	WLAN-Aux	To top	350
H	WLAN-Aux	To left	334.84
I	WLAN-Aux	To right	8.83
J	WLAN-Aux	To bottom	15.7
K	WLAN-Aux	Aux antenna length	6.7
L	NB	Bumper thickness	1.5
X	WLAN-Main	To user	80.6
Y	WLAN-Aux	To user	80.6
Z	NB	Keyboard depth	238

Antenna Host Platform location


The diagram illustrates the layout of the Antenna Host Platform. It is a rectangular device with four sides labeled: Left, Right, Front, and Rear. A Keyboard is located on the Rear side. Four antenna locations are marked with letters M, N, O, and P, each with a double-headed arrow indicating its orientation. M and O are located on the Front side, while N and P are located on the Rear side. M and N are connected to the WLAN Main port, and O and P are connected to the WLAN Aux port. The WLAN Main port is on the Left side, and the WLAN Aux port is on the Right side.

Minimum Separation Distance			
Item	Antenna	Position	Distance (mm)
M	WLAN-Main	To front	6.82
N	WLAN-Main	To rear	4.35
O	WLAN-Aux	To front	6.82
P	WLAN-Aux	To rear	4.35

Antenna Host Platform location	
	

F.4 Phantom liquid level during measurements

ELI phantom Body liquid SAR Dasy SPEAG MBL600-6000V6 Batch 160630-01



End of the report

This page is intentionally left blank and marks the last page of the test report.