


Annex F. Photographs

F.1 Test Sample



F.2 Test positions

Laptop



F.3 Antenna host platform location and adjacent edge positions relative to the body

All information (diagrams, values and dimensions) in this section is provided by the manufacturer

Antenna Host Platform location

Diagram illustrating the Antenna Host Platform location on a laptop. The diagram shows the laptop's layout with labels for Top, Bottom, Left, Right, Display, Keyboard, WLAN Main, and WLAN Aux. Dimensions A through L are indicated, representing various distances and lengths. A note specifies "NB mode open 90°".

Diagram illustrating the Antenna Host Platform location on a laptop, showing a top-down view of the keyboard area. Labels include Top, Bottom, Left, Right, Display, Keyboard, WLAN Main, and WLAN Aux. Dimensions A through L are indicated, representing various distances and lengths. A note specifies "NB mode open 90°".


Antenna Host Platform location

Minimum Separation Distance			
Item	Antenna	Position	Distance (mm)
A	WLAN-Main	To top	350
B	WLAN-Main	To left	8.83
C	WLAN-Main	To right	334.84
D	WLAN-Main	To bottom	15.7
E	WLAN-Main	Main antenna length	6.7
F	Main-Aux	Main to Aux	336
G	WLAN-Aux	To top	350
H	WLAN-Aux	To left	334.84
I	WLAN-Aux	To right	8.83
J	WLAN-Aux	To bottom	15.7
K	WLAN-Aux	Aux antenna length	6.7
L	NB	Bumper thickness	1.5
X	WLAN-Main	To user	80.6
Y	WLAN-Aux	To user	80.6
Z	NB	Keyboard depth	238

Antenna Host Platform location


The diagram illustrates the layout of a laptop with a keyboard. The laptop is oriented with 'Front' at the top and 'Rear' at the bottom. The left and right sides are labeled 'Left' and 'Right' respectively. A 'Keyboard' is positioned in the center. Four antenna locations are marked: 'M' (WLAN-Main) is located near the front-left corner; 'N' (WLAN-Main) is located near the rear-left corner; 'O' (WLAN-Aux) is located near the front-right corner; and 'P' (WLAN-Aux) is located near the rear-right corner. Double-headed vertical arrows indicate the distances from the keyboard to each antenna location: M to front, N to rear, O to front, and P to rear.

Minimum Separation Distance			
Item	Antenna	Position	Distance (mm)
M	WLAN-Main	To front	6.82
N	WLAN-Main	To rear	4.35
O	WLAN-Aux	To front	6.82
P	WLAN-Aux	To rear	4.35

Antenna Host Platform location


F.4 Phantom liquid level during measurements

ELI phantom Body liquid SAR Dasy SPEAG MBL600-6000V6 Batch 160630-01



End of the report

This page is intentionally left blank and marks the last page of the test report.