


Annex A. Photographs


A.1 Setup Photo



A.2 Test sample



Main Antenna

Antenna Drawing





Antenna Photo

Front




[Back](#)




Aux Antenna

Antenna Drawing





Antenna Photo

Front



[Back](#)




Annex B. Antenna Location

B.1 Antenna Host Platform Location Information

Include a dimensioned photo(s) or dimensioned drawing(s) of Main and Aux antenna placements (measurements are not required for receive-only antenna).


Any antenna that transmits must show dimensions to bottom of laptop. Provide a description of the materials that are used for supporting or surrounding transmit antennas; for example, non-conductive plastics vs. conductive coated plastic or metallic materials.

Laptop mode




Tablet mode:

WLAN Main Tx1



WLAN Aux Tx1




B.2 Antenna dimensional information for SAR evaluation

Include a dimensioned photo(s) or dimensioned drawing(s) showing the distance (mm) between the transmit antennas and the user. For notebook/laptop hosts show lapheld position (example below). For tablet hosts show all orientations including lapheld, primary & secondary portrait, primary & secondary landscape positions. Include a description of any proximity sensors or power throttling implementations that limit or exclude use of any host orientation.

Antennas on the panel section


Laptop mode:





Measuring Surface	Antenna	Separation Distance(antenna-to- Surface)(mm)	1g SAR
Bottom Side	Main	204	FCC/ISED
	Aux	204	FCC/ISED

Tablet model:

WLAN Main Tx1



WLAN Aux Tx1



Measuring Surface	Antenna	Separation Distance(antenna-to- Surface)(mm)	1g SAR
Bottom Side of Tablet mode	Main	15.96	FCC/ISED
	Aux	15.96	FCC/ISED
top edge of Tablet mode	Main	197	FCC/ISED
	Aux	197	FCC/ISED
bottom edge of Tablet mode	Main	3	FCC/ISED
	Aux	3	FCC/ISED
left edge of Tablet mode	Main	21.6	FCC/ISED
	Aux	208.4	FCC/ISED
right edge of Tablet mode	Main	208.4	FCC/ISED
	Aux	22	FCC/ISED