


# Annex A. Photographs

---

## A.1 Setup Photo





## Antenna Drawing





## Antenna Photo

Front




Back



Note: antenna photo should include L type ruler


## Aux Antenna

## Antenna Drawing




## Antenna Photo

Front



Back




Note: antenna photo should include L type ruler

# Annex B. Antenna Location

## B.1 Antenna Host Platform Location Information

Include a dimensioned photo(s) or dimensioned drawing(s) of Main and Aux antenna placements (measurements are not required for receive-only antenna).


Any antenna that transmits must show dimensions to bottom of laptop. Provide a description of the materials that are used for supporting or surrounding transmit antennas; for example, non-conductive plastics vs. conductive coated plastic or metallic materials.



## B.2 Antenna dimensional information for SAR evaluation


Include a dimensioned photo(s) or dimensioned drawing(s) showing the distance (mm) between the transmit antennas and the user. For notebook/laptop hosts show lapheld position (example below). For tablet hosts show all orientations including lapheld, primary & secondary portrait, primary & secondary landscape positions. Include a description of any proximity sensors or power throttling implementations that limit or exclude use of any host orientation.

### Antennas on the panel section



| Measuring Surface | Antenna | Separation Distance(antenna-to- Surface)(mm) | 1g SAR   |
|-------------------|---------|----------------------------------------------|----------|
| Bottom Side       | Main    | <b>NB: 3.95; Pad: 4.25</b>                   | FCC/ISED |
|                   | Aux     |                                              | FCC/ISED |

## Antennas on the keyboard section



| Measuring Surface    | Antenna | Separation Distance(antenna-to-Surface)(mm) | 1g or 10g SAR |
|----------------------|---------|---------------------------------------------|---------------|
| Bottom Side          | Main    | <b>NB: 3.95; Pad: 4.25</b>                  | 1g (FCC/ISED) |
|                      | Aux     | <b>NB: 3.95; Pad: 4.25</b>                  | 1g (FCC/ISED) |
| Front Edge           | Main    |                                             | 1g (ISED)     |
|                      | Aux     |                                             | 1g (ISED)     |
| Left Edge            | Main    |                                             | 10g (ISED)    |
|                      | Aux     |                                             | 10g (ISED)    |
| Right Edge           | Main    |                                             | 10g (ISED)    |
|                      | Aux     |                                             | 10g (ISED)    |
| Top side of Keyboard | Main    |                                             | 10g (ISED)    |
|                      | Aux     |                                             | 10g (ISED)    |