


SR-119 Remote Controller

The key chain Remote Controller is a convenient way to arm (For Home, or Away) and disarm to this system. It also has a Panic key feature.



Arming with the Remote Controller

1. Press the Home key or Away depends on what Alert Mode you want.
2. The Arm LED on the Main console panel lights and the LCD panel displays Alert.

Disarm with the remote controller

1. Press the Disarm key.
2. The Arm LED light on the Main Console switch off and the alert display disappear.

Using the Panic Key -

Press the Panic key to activate the alarm and automatic dialer immediately. The Auto-dialer will operate even if the system is disarmed.

63 Remote System
01 Disarmed

Note : This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference
and (2) this device must accept any interference
received, including interference that may cause
undesired operation.

63 Remote System
01 Armed AWAY

Notice : The changes or modifications not expressly
approved by the part responsible for compliance
could void the use's authority to operate the
equipment.

63 Remote System
01 Armed HOME

63 Remote System
01 PANIC