

# MANUAL

BLUETOOTH WIRELESS PORTABLE SPEAKER

MODEL NO: DC-0233



**WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,  
DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.**

Please read this before operating your unit.


# IMPORTANT SAFETY INSTRUCTIONS

1. **READ INSTRUCTIONS** - All the safety and operating instructions should be read before the product is operated.
2. **RETAIN INSTRUCTIONS** - The safety and operating instructions should be retained for future reference.
3. **HEED WARNINGS** - All warnings on the product and in the operating instructions should be adhered to.
4. **FOLLOW INSTRUCTIONS** - All operating and use instructions should be followed.
5. **CLEANING** - Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. **ATTACHMENTS** - Do not use attachments not recommended by the product manufacturer as they may cause hazards.
7. **WATER AND MOISTURE** - Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement, or near a swimming pool, and the like.
8. **ACCESSORIES** - Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
9. A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



10. **VENTILATION** - Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
11. **POWER SOURCES** - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to operating instruction.

## Know your speaker



- A. On/ Off button (OFF/ AUX/ BT)
- B. AUX in/Charging light (Green )
- C. USB DC 5V
- D.Bluetooth indicator light (Blue)
- E.Charging indicator light (Red)
- F.Prev
- G.Volume-
- H.Volume+
- I.Next
- J.Pause/ Play/ Hands free answer/ Hands free hang up/LONG PRESS SWITCH OFF
- K.MIC

## The Reasons why you love it

- Compatible with the Iphone, Ipad or any cell phone has Bluetooth, enjoy your loved song anytime, anywhere.
- Can control the play mode through the speaker, makes everything convenient.
- Wireless Bluetooth connection, effective range

can reach to 10m, enjoys music boundless.

- Automatically snooze mode, smart energy conversation.
- USB charge support, easy for operation.
- AUX-in also bring good performance in sourcing music device connection.
- Hands free phone call mode.

### **Product Specifications**

- Dimension & Weight

Dimension: 98.5mm (W)\*74.5mm (D)\*67.5mm (H)

Weight: 270g± 5% for speaker body

- Standard Battery: Built in rechargeable 800mAh Lithium battery

- Music playtime: Max 6-8 hrs(based on 50%-70% voice volume)

- Charge condition:

Charge time: 3-4 hours

Power input:DC 5V/500mA.

### **Speaker Specifications**

- Diameter: 2 inch
- Impedance: 4Ω
- Power output: 3W
- dB SPL: 80 ± 3dB 1W/M

### **Wireless function**

- Frequency: 2.402-2.480 GHz

- Max transmission power rate: 2 grade, 4dBm
- Receiving sensitivity: -82dBm
- Transmission distance: within 10 meters
- Data transmission rate: 3Mbps

### **Package & accessories**

- QUICK START GUIDE
- Bluetooth Speaker
- USB cable
- Audio cable
- Instruction manual
- Warranty card

### **Operation Instructions**

1. Turn on ON/OFF switch to AUX-in, the green indicator light on, and the speaker is in the AUX-in function. Turn the switch to BT (Bluetooth) position, and speaker will have a response ring, the blue indicator light flash and the green indicator also light on , Bluetooth function is available.
2. When connect to the USB DC in or adaptor, red indicator light on, charge mode work. The speaker can be charged when it's in ON or OFF status.(We suggest to turn off speaker when charge it.)
3. The Bluetooth speaker will turn into snooze mode after 5 minutes unused(means do not connect with bluetooth and User can setting time), and speaker will have a continuous warning tone.

Turn on the ON/OFF switch again, and the speaker will turn into the normal working mode.

Below operations are available only under Bluetooth mode:

4. Short press "+", volume up; Short press "-“, volume down.

5. Short press “” for previous song; Short press “” for next song.

6. In the play mode, short press “” is pause/play function; When phone call comes, there is response ring, short press “” to answer phone with hands free; In the phone mode, press “” to hang up the phone conversation.

When fast press the “” two times, it will call dialed the last number in the cell phone automatically, support the voice dial function.

7. When blue indicator flashes fast, Bluetooth is searching signal, after successful matched, the blue indicator light will be bright and flash slowly.

8. The Bluetooth speaker can only match to one signal per time, the connection can not be deleted when matching. It can only be deleted in disconnection model.

9. It's not allow to show the same equipment name in the Bluetooth connection list, or it will make the one in same name can not be connected.

10. The Bluetooth speaker user name is: Sylvania BT, the password is: “0000”.

### Points to keep your Bluetooth energetic

- The hands free function can only be worked in the Bluetooth mode.
- The Bluetooth speaker has a anti signal disturb design, but it will still be interrupted by the high frequency device or within electromagnetic field. Avoid to put it in such kind of environment.
- Different user port will make difference on the transmission distance. Please use the qualify Bluetooth port.
- Some cell phone music player device does not have smooth cache, and it will be a slightly "POP" tone when pause, it's a normal sound.
- The disconnection of Bluetooth is not a real time operation, and it will be a few seconds delay from the cell phone operation.
- When Bluetooth match is failed, delete other Bluetooth device in the connection list, restart the Bluetooth speaker and search the signal again.
- If speaker makes a loud electronic noise, or when charging by USB port, the red, green, blue indicator light flashes in turn, please check for the battery shrapnel, or if any damage in the battery.
- It must install a Bluetooth media player in the computer when PC using the Bluetooth speaker.
- Please pull out the AUX-in cable before connecting to the Bluetooth speaker, to make**

**sure the connection is correct.**

- The speaker sound effect is affected by battery capacity, cell phone performance and input media source quality. If noise, user can download some ““0dB” music for test in AUX-in mode, in the distance of 1m.
- If speaker will not be used for a long time, please keep charge once per month, to avoid the over-consumption of the battery to damage the speaker.
- Do not put the speaker in an extreme cold, hot, wet or dusty environment, or it will be damage to the function and device.
- Do not use the speaker in an extreme dry environment, to avoid the static damage.
- Do not put the speaker into water or fire.
- Do not scratch the speaker to protect the interface and battery.

**Thanks for using Our Bluetooth speaker  
Enjoy music, enjoy life!**

## FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference.
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body