



Operational Description

Section 1: Installation

- **Placement and Power Connect**

1. Place the system on your desk or any other place for easy access and connect AC-DC 12V adaptor.

- **Input Connection**

1. Input Connection the Line out of PC Sound Card to the Line In connectors of SDC-800T.

Connect the stereo line output of PC Sound Card to the Line-In of SDC-800T

2. If your PC Sound Card has S/PDIF Digital output, then connect them to Digital input of SDC-800T depending on the type of connector (Optical or Coaxial-RCA)
3. Please refer the following pages for typical input connections of SDC-800T. But those are not all. You may find various applications for SDC-800T by your own.

- **Output Connection and Speaker Mode Setting**

1. Based on availability of multimedia PC speakers and power amplifiers, connect them to the proper line output of SDC-800T and set/reset "Speaker Mode DIP Switch" bits according to front speaker size and existence of rear speakers.
2. Existence of center and sub-woofer is automatically detected. So, if you gave good sub-woofer amplifier, simply connect it to the Sub Woofer Line Out connector of SDC-800T. No additional configuration is needed.
3. Please refer the following pages for typical speaker connections and DIP switch settings of SDC-800T. Also, those are not all. You may also find another applications for SDC-800T by your own.

- **Speaker Test**

1. After Power On, by pressing Test Tone button in Remote control Panel, initiate speaker test mode, and verify correct speaker positioning and
2. Also adjust individual volume level if necessary.
3. When everything done, press any button and return to normal operation mode.



Section 2: How to operate

1. Installation and Speaker Setting

As explained in previous chapter, complete the installation and speaker setup. Perform speaker test, and verify correct positioning and volume level.

2. Executing PC S/W or Playing Audio Source Attached

Execute S/W DVD Player, WinAMP or Media Player if you have connected the system to PC sound card.

If you also have attached other audio source like portable CDP, start playing it.

3. Volume Adjustment and Input Selection

Adjust master or individual volumes again if needed. And also select proper connected to audio source that you want to listen and enjoy.

4. Select Proper Surround Mode

Finally choose the most comfortable surround mode to your taste.