

Photo 1: External photo of EUT (Base)



Photo 2: External photo of EUT (Base)



Photo 3: External photo of EUT (Base)



Photo 4: External photo of EUT (Base)



Photo 5: External photo of EUT (Handset)



Photo 6: External photo of EUT (Handset)



Photo 7: External photo of EUT (Handset)



Photo 8: External photo of EUT (Handset)



Photo 9: External photo of Adapter



Photo 10: External photo of Adapter



Photo 1: Internal photo of EUT (Base)



Photo 2: Internal photo of EUT (Base)

Antenna



Photo 3: Internal photo of EUT (Base)



Photo 4: Internal photo of EUT (Base)




Photo 5: Internal photo of EUT (Base)




Photo 6: Internal photo of EUT (Base)




Photo 7: Internal photo of EUT (Base)




Photo 8: Internal photo of EUT (Base)




Photo 9: Internal photo of EUT (Base)




Photo 10: Internal photo of RF modular (Base)




Photo 11: Internal photo of EUT (Handset)



Photo 12: Internal photo of EUT (Handset)



Photo 13: Internal photo of EUT (Handset)




Photo 14: Internal photo of EUT (Handset)




Photo 15: Internal photo of EUT (Handset)




Photo 16: Internal photo of EUT (Handset)




Photo 17: Internal photo of EUT (Handset)




Photo 18: Internal photo of EUT (Handset)




Photo 19: Internal photo of EUT (Handset)




Photo 20: Internal photo of EUT (Handset)




Photo 21: Internal photo of EUT (Handset)




Photo 22: Internal photo of EUT (Handset-Battery)

