

1) Place your clock near a window and away from metal surfaces or electrical appliances.

2) If the clock does not catch the signal in the first 20 minutes, then set the clock manually. The Atomic clock will adjust itself to the exact time within 48 hours.

FOR CUSTOMER INQUIRIES:

TEL : (757) - 460-2483

EMAIL: eicladay@aol.com

