

Alignment Procedure

The item comes form the factory tuned. Only a qualified technician is allowed to tune this transmitter.

Equipment needed:

a service monitor that can measure field strength and frequency.

Tuning tool.

1. Adjust the service monitor to the channel frequency. (72MHz)

2. Tune T1,T2 for maximum output.