

No. 98700

For Ages 6 and Up

R/C MOTORCYCLE MONSTER DIRT BIKE

OWNER'S MANUAL

Please read thoroughly before operating your cycle. Keep these instructions for future reference.

FEATURES

- Full function
- Frequency : 27 MHz
- Range up to 65/20m

Formative International Co., Ltd.
JOB #: 354H1
FCC ID: PKZ700271
EXHIBIT : 3

I. CONTENTS I



(1) MONSTER DIRT BIKE Cycle



(1) Transmitter




(6) AA size batteries



(1) 9V size battery

CYCLE


TOP VIEW



Powerful
Motor

Heavy-duty
Suspension

BOTTOM VIEW




ON/OFF
Switch

Battery
Compartment

TRANSMITTER

NOTE: Your transmitter is equipped with a special automatic ON battery-saving feature. Just turn your cycle ON. Then push either transmitter stick and you will be able to run control your cycle.



Automatic "ON" Power Indicator Light

II. QUICK START I

1. Start with fresh batteries.
2. Turn cycle switch ON. Press transmitter controls to run and control your cycle.
3. When you're done driving, turn cycle switch OFF. Remove all batteries for storage.

Formative International Co., Ltd.

JOB #: 354H1


FCC ID: PKZ700271

EXHIBIT : 4


III. OPERATING YOUR CYCLE I

Move (L/R) stick(s) as indicated by solid arrows. Cycle will move in direction as indicated by outline arrow.


FORWARD



FORWARD "TURBO"



BRAKING



LEFT TURN



RIGHT TURN



NOTE: IF YOUR CYCLE GETS STUCK OR STALLS, RELEASE THE CONTROL STICKS, REPOSITION YOUR CYCLE AND START AGAIN!

Formative International Co., Ltd.


JOB #: 354H1

FCC ID: PKZ700271

EXHIBIT : 5

IV. QUICK TIPS I

1. When your cycle starts to lose power, it may lose functions or performance. It's time for batteries. Your cycle's running time may change depending on your driving style.
2. Radio interference can make your cycle run badly. Interference can be caused by other R/C vehicles running on the same frequency; electrical wires; large buildings; or CB radios. Try to stay away from these!
3. Point your transmitter antenna up - not down toward your cycle. If your cycle gets too far away, it won't work properly.
4. Don't drive your cycle in sand or through water or snow. If your cycle does get wet, wipe with a towel and allow drying completely.
5. Don't store your cycle near heat or in direct sunlight. Always turn switches OFF and remove all batteries for storage.



V. BATTERY INSTALLATION I

CYCLE



1. Turn cycle over, open the battery compartment cover to remove the battery pack.
2. Remove the screw and release the locks to open the battery pack.
3. Install 6 x 1.5V SIZE "AA" alkaline batteries with polarity (+/-) as shown.
4. Close the battery pack by securing the locks and screw. Insert battery pack into the battery compartment and close the cover.

Estimated run time for this cycle : 15-20 minutes

TRANSMITTER

1. Install one 9-volt battery with polarity (+/-) as shown inside battery compartment.
2. The 9-volt transmitter battery will last much longer than the run time of the cycle batteries.

Formative International Co., Ltd.
JOB #: 354H1
FCC ID: PKZ700271
EXHIBIT : 6



VI. BATTERY INFORMATION I

- Batteries should be replaced UNDER ADULT supervision.
- Ensure batteries are CORRECTLY INSERTED observing the +/- signs.
- Do not attempt to recharge batteries.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not dispose of battery in fire.
- Remove the batteries from toy when not in use or when exhausted.

VII. CAUTIONS I

Adults, this toy recommended for children 6 years of age and older. To ensure that child's play is both safe and fun, please review the operating instructions and these general safety rules with the child.

Caution

- DO NOT pick up cycle while in motion.
- Keep fingers, hair and loose clothing away from the tires and the wheel hubs while the cycle is switched ON.
- If this toy is being operated in the presence of children under 6 years of age, adult supervision is recommended.
- To avoid accidental operation, remove all batteries when not in use.
- DO NOT OPERATE your cycle on streets! They're for real cars!

COMPLIANCE WITH FCC REGULATIONS
THIS DEVICE COMPLIES WITH PART 15 OF THE
FCC RULES. OPERATION IS SUBJECT TO THE
FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL
INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY
INTERFERENCE RECEIVED, INCLUDING
INTERFERENCE THAT MAY CAUSE UNDESIRABLE
OPERATION.
This device generates and uses radio frequency energy
and if not used properly may cause interference to radio
and television reception. It has been tested and found to
comply with the limits set by the FCC, which are
designed to provide reasonable protection against such
interference.
CAUTION: FCC Regulations state that changes or
modifications to this product not expressly approved by
the party responsible for compliance could void the
user's authority to operate the equipment.