



## 12. SETUP PHOTOS


### ANTENNA PORT CONDUCTED RF MEASUREMENT SETUP



**RADIATED RF MEASUREMENT SETUP (BELOW 1 GHz)**




RADIATED BACK PHOTO (BELOW 1 GHz)



**RADIATED RF MEASUREMENT SETUP (ABOVE 1 GHz)**

RADIATED FRONT PHOTO (ABOVE 1 GHz)




RADIATED BACK PHOTO (ABOVE 1 GHz)




**RADIATED RF MEASUREMENT SETUP FOR PORTABLE CONFIGURATION**


X-AXIS FRONT PHOTO




X-AXIS BACK PHOTO




Y-AXIS FRONT PHOTO




Y-AXIS BACK PHOTO



Z-AXIS FRONT PHOTO





Z-AXIS BACK PHOTO



**POWERLINE CONDUCTED EMISSIONS MEASUREMENT SETUP**

**EUT A/DC adapter connected to LISN**



**POWERLINE CONDUCTED EMISSIONS MEASUREMENT SETUP**

**Laptop connected to LISN**

LINE CONDUCTED FRONT PHOTO



LINE CONDUCTED BACK PHOTO



**DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP**

DFS FRONT PHOTO (EUT)



DFS BACK PHOTO (EUT)

