







Antenna Location

NB Mode




Separation Distance (mm)	Wi-Fi Antenna (Main)	Wi-Fi Antenna (Aux)
Top-Edge (Edge1)		
Right-Edge (Edge2)		
Bottom-Edge (Edge3)		
Left-Edge (Edge4)		
Bottom	190	190

Tablet Mode




Separation Distance (mm)	Wi-Fi Antenna (Main)	Wi-Fi Antenna (Aux)
Top-Edge (Edge1)	5	5
Right-Edge (Edge2)	46	176.2
Bottom-Edge (Edge3)	165	165
Left-Edge (Edge4)	209.2	79
Rear Surface	14.5	14.5

Stand Mode




Separation Distance (mm)	Wi-Fi Antenna (Main)	Wi-Fi Antenna (Aux)
Top-Edge (Edge1)	5	5
Right-Edge (Edge2)	46	176.2
Bottom-Edge (Edge3)	190	190
Left-Edge (Edge4)	209.2	79
Rear Surface	14.5	14.5

Tent Mode




Separation Distance (mm)	Wi-Fi Antenna (Main)	Wi-Fi Antenna (Aux)
Top-Edge (Edge1)	5	5
Right-Edge (Edge2)		
Bottom-Edge (Edge3)		
Left-Edge (Edge4)		
Rear Surface		

SETUP PHOTOS



Edge 1



Rear



Edge 2

EUT Photos

