


Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)

AC Adapter 4



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)



Host: Notebook Computer


(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)

AC Adapter 5



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)



Host: Notebook Computer


(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)

Battery 1



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)


Battery 2



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)


Battery 3



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)


Battery 4



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)

Battery 5



Host: Notebook Computer

(Brand Name: Lenovo / Model Name: Lenovo IdeaPad S340-14IWL / Lenovo IdeaPad S340-14API)

Battery 6

