

Limited Warranty Information

WHAT IS COVERED:

To the original consumer/purchaser within the united states or canada that our Cleopatra's Needle II lamp shall be free of manufacturers defects in material and workmanship for the period of 90 days from date of purchase under normal Non-commercial use.

WHAT WE WILL DO:

During the warranty period we will at our option repair or replace the Cleopatra's Needle II lamp without charge and the cost of return freight charges to the original consumer providing the product was delivered to us with proof of purchase, postage and insurance prepaid.

LIMITATIONS:

THIS WARRANTY DOES NOT COVER CONSEQUENTIAL DAMAGES, AND THE LIABILITY OF THE SELLER IS LIMITED TO THE REPAIRING OR REPLACING THE CLEOPATRA'S NEEDLE II IN ACCORDANCE WITH THE STIPULATIONS CONTAINED IN THIS WARRANTY. NO OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE.


The warranty shall not apply to any goods that have been repaired or altered by anyone other than seller. The warranty shall not apply to any goods subject to misuse due to common negligence or accident, nor to any goods made by seller that are not operated in accordance with the printed instructions of seller or that have been operated beyond the rated capacity of the goods.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION SET FORTH ABOVE.

OWNERS MANUAL

Cleopatra's
Needle II

- USERS INSTRUCTIONS
- WARRANTY



HISTORY

OBELISK - Definition : A tall four sided pillar . Wider at the square or rectangular base and narrower at the top. The original Obelisk date back to the 4th dynasty (c.2613-2494 BC)

CLEOPATRA'S NEEDLES

Late in the 19th century Egypt divided a pair of obelisk giving one to the United States in 1881 and the other to Great Britain . One now stands in Central Park in New York City, and the other on the Thames embankment in London. Although they were named Cleopatra's Needles they have no historic connection to the Famous Egyptian Queen. They were originally dedicated at the great temple of Heliopolis ,where Moses was born by Thutmose III about 1500BC and bear inscriptions to him and to Ramses II (.1304-c. 1237 BC).They are carved from rose-red granite of syene ,they stand 69 feet, 6 (21.2m) and weigh 180 Tons.

CAUTION
RISK OF ELECTRICAL SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT ATTEMPT TO OPEN THE BASE OF THE PRODUCT. DO NOT ATTEMPT TO REMOVE THE GLASS DOME. THERE ARE NO USER-SERVICEABLE PARTS INSIDE. SERVICE SHOULD BE HANDLED ONLY BY QUALIFIED SERVICE PERSONNEL.

The triangle containing the lightning flash is to alert users to the risk of electrical shock due to possible dangerous levels of uninsulated voltage inside the unit's casing.

The triangle containing the exclamation point is to alert the user that important operation instructions are contained in the literature accompanying the unit.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO MOISTURE

PRODUCT STATEMENT

The Cleopatra's Needles II lamp uses a radio frequency.

It complies with all limits of the FCC rules and regulations.

These regulations are designed to provide some protection against radio and TV interference.

RF Interference:

If you experience any radio or TV interference unplug the Cleopatra's

Needle II lamp and move away from the radio or TV. Use different

outlets to operate the radio and or TV set. For best results keep at

least two feet or 60 cm away from other electronic devices.

Contact customer service of supplier if problem still exists.

SPECIFICATIONS:

POWER SOURCE: 120 VOLTS AC 60 Hz

POWER CONSUMPTION: 18 WATTS

Specifications subject to change without notice

U.L Listed, E186846

Description

The Cleopatra Needle II Lamp comes with a durable molded plastic housing and a 1 piece glass obelisk injected with a safe gas that allows its effects. Enclosed in the molded plastic housing is an electronic circuit that allows the lamp to display an array of electrical charges.

With proper use and care the Cleopatra's Needle II Lamp will give you many hours of extraordinary entertainment. By touching the Obelisk's surface you can alter the effect of the energy for added entertainment. By using your lamp in a room with low light it's effects will be more brilliant.

Introduction instructions

Carefully unpack your lamp to avoid injury or damage since the Glass

Obelisk is fragile if you find the Cleopatra's Needle Lamp is damaged in

any way Do not plug in to operate or test.

Setting up:

Your Cleopatra's Needle Lamp has a Polarized plug designed for indoor use with a polarized receptacle. THIS LAMP IS DESIGNED FOR INDOOR USE ONLY.


Be sure the lamp is placed on a stable surface. Away from lamp locations with power cord in a safe location as to prevent lamp from being pulled off of the table or surface.

OPERATION

The power switch is located on the front of the base of the lamp. Pushing the switch in one time turns the power on and illuminates the lamp. Pressing the switch again turns the power off.

AUDIO SENSOR:

For models equipped with audio sensor. The lamp will illuminate when sounds are produced. This feature can be activated by depressing the audio sensor switch located to the right of the power switch.



Placing your hand near the glass obelisk or touching the Obelisk will cause interference of the free electrons causing different patterns of light produced by the lamp.

WARNING: ONLY TOUCH GLASS WITH DRY HANDS.

DO NOT LEAVE HAND ON LAMP FOR EXTENDED PERIOD OF TIME. This will cause excessive heat build up as with any lighting fixture and possible discomfort. **DO NOT TOUCH THE GLASS WITH METAL OBJECTS.**

USE UNDER ADULT SUPERVISION.

Maintenance

The Cleopatra's Needles II lamp was designed to provide many hours of enjoyment with quality materials. Please follow these suggestions for care and Maintenance.

1. Place in normal living environment. Extreme temperature conditions will shorten the life of any electronic device and cause damage to the housing.
2. Keep dry—Moisture can cause damage to electronic circuits. If lamp gets wet unplug from socket and wipe dry with soft cloth as soon as possible. **NEVER IMMERSE FIXTURE IN WATER.**
3. Dust can cause the switches to malfunction. If your Cleopatra's Needle II lamp needs cleaning unplug the fixture from the power supply and Again use soft dry cloth. Use of glass cleaner is ok on the glass obelisk. Spray cleaner on soft cloth and wipe fixture gently.
4. Always handle with care. The glass obelisk is fragile and could break on impact if dropped or bumped. Also damage to electronic circuits could occur. Unplug lamp immediately if any damage occurs.
5. Never attempt to modify or tamper with any of the internal parts. If the lamp is not working properly return it to the place of purchase.
6. Do not plug into a power source other than a 120 volt AC, 60 Hz electrical outlet. The use of an extension cord is not recommended.