


External Photos

Model Number:


AW-CM467-SUR 、 AW-CM467-SUR-I

AW-CM467-USB 、 AW-CM467-USB-I


EUT Photo (1)



EUT Photo (2)



EUT Photo (3)



EUT Photo (4)



EUT Photo (5)



Host: M2-UM188-ETK3ER (RFID)

EUT Photo (1)



EUT Photo (2)



EUT Photo (3)



EUT Photo (4)



EUT Photo (5)



EUT Photo (6)



EUT Photo (7)



EUT Photo (8)



Host: M2-UK188-ETK3ER (RFID)

EUT Photo (1)



EUT Photo (2)



EUT Photo (3)



EUT Photo (4)



EUT Photo (5)



EUT Photo (6)



EUT Photo (7)



EUT Photo (8)



Host: M2-UM188-ETK3EP (POS)

EUT Photo (1)



EUT Photo (2)



EUT Photo (3)



EUT Photo (4)



EUT Photo (5)



EUT Photo (6)



EUT Photo (7)



EUT Photo (8)



EUT Photo (9)



EUT Photo (10)



EUT Photo (11)



Host: M2-UK188-ETK3EP (POS)

EUT Photo (1)



EUT Photo (2)



EUT Photo (3)



EUT Photo (4)



EUT Photo (5)



EUT Photo (6)



EUT Photo (7)



EUT Photo (8)



EUT Photo (9)



EUT Photo (10)



EUT Photo (11)

