

TABLE OF CONTENTS

Battery Precautions	2
FCC Information	3
Location of Parts and Controls	4
Charging your iPad Tablet	5
Charging the Keyboard	5
Syncing the Bluetooth® to your iPad Tablet	6
Specifications	7
Troubleshooting	8
Warranty	9

suppliers other than Brookstone may provide their own warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or

BATTERY PRECAUTIONS

- Dispose of old batteries properly. Do not dispose of old batteries in a fire.
- Do not leave batteries where a young child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- Batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

Modifications not authorized by the manufacturer may void the user's authority to operate this device.

TROUBLESHOOTING

ISSUE

The keyboard will not work with my iPad Tablet.

SOLUTION

Make sure that the keyboard is synced correctly. Power the keyboard off and then on and try again.

If the iPad Tablet has been upgraded, or you are using a different iPad Tablet, resync using the steps on the previous pages.

Check the battery power. You may need to recharge the Bluetooth® Keyboard




Make sure that both your iPad Tablet and the Bluetooth® Keyboard are on and in good working order.

iPad is a trademark of Apple Inc., registered in the U.S. and other countries.
Bluetooth is a registered trademark of Bluetooth SIG, Inc.

SPECIFICATIONS

Bluetooth®	V3.0
Bluetooth® Working Distance	32'
Operating Voltage	3.0 - 5.0V
Charging Means	USB 2.0
Charging Time	4 - 4.5 hours
Battery Usage Time	Up to 90 continuous hours
Battery Life	3 years
Dimensions	11.22" (L) x 9.84" (W) x 5.09" (H) /Standard Position 11.22" (L) x 4.54" (W) x 6.70" (H)/ Folded Position
Charging USB Ports, Output voltage	5V, 2.1A (total)
DC Input	5V, 2.2A

LOCATION OF PARTS AND CONTROLS



CHARGING YOUR iPad TABLET

1. Connect the DC adapter (included) to the wall let and plug another end to the DC-IN jack of the Station.
2. Connect your own 30-pin USB cable to your iPad Tablet and plug another end (USB male) of the cable to one of the charging USB ports on Station.
3. You can charge one iPad Tablet and one Keyboard in the same time.

Note: The charging ports cannot charge two Tablets at the same time.

CHARGING THE KEYBOARD

1. Plug the charging cord (included) into the charging outlet at the control panel and into a USB outlet
2. The power and charging LEDs will illuminate during charging, and shut off when charging is complete.
3. The keyboard takes approximately 4.5 hours to charge for up to 90 hours of use.

Note: The charging LED indicator will blink when your Bluetooth® Keyboard Case's battery needs recharging.

SYNCING THE BLUETOOTH® TO YOUR iPad Tablet

1. Power on your iPad Tablet.
2. Slide the On/Off switch on the Bluetooth® Keyboard to "on". Both the Bluetooth® LED and the Power LED will light up. The Bluetooth® LED will shut off after a few seconds, but the Power LED will remain illuminated.
3. Press the Connect button on the Bluetooth® Keyboard. The Power LED will illuminate and the Bluetooth® LED will flash.
4. Select the "Settings" icon on your iPad Tablet's screen.
5. Locate and select "Bluetooth" in your iPad Tablet's "General" menu.
6. Under "Devices" on your iPad Tablet, select the Bluetooth® Keyboard
7. The iPad Tablet will now prompt you to enter your computer Bluetooth® password and press either the Return or Enter key using the Bluetooth® Keyboard.
8. The iPad Tablet screen should now show the Bluetooth® Keyboard has connected successfully.
9. The Power LED will remain illuminated while the keyboard is powered on.
10. Slide the On/Off switch to "off" when you are done using the keyboard.
11. If your iPad Tablet goes into standby mode, the Bluetooth® Keyboard should still be synced. If you power-off your iPad Tablet you may need to re-sync. If you use the Bluetooth® Keyboard with a new iPad Tablet, or it doesn't connect properly, follow the steps above to re-sync.

Note: The Bluetooth® Keyboard will automatically go into standby mode after 15 minutes of non-use in order to preserve battery life. Just press any key to reactivate the keyboard.