

Use this Procedure for Vehicles with Driver Information Center Buttons

This information is in your vehicle Owner's Manual in the Drivers Information Center Section

1. Insert Key and turn to ON position so you can access Drivers Information Center
2. Press the vehicle's information button until **PRESS TO RELEARN REMOTE KEY** displays.
3. Press the set/reset button until **REMOTE KEY LEARNING ACTIVE** displays.
4. Press and hold the lock and unlock buttons on the first keyless remote at the same time for approximately 15 seconds. A chime will sound indicating that the remote is programmed
5. To program additional remotes at this time repeat Step 4. This vehicle can have a maximum of eight remotes programmed.
6. To exit programming mode turn the key off and remove key. Test remote(s)

FCC WARNING

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

IC WARNING

The term IC before the Certification/Registration number only signifies that the Industry Canada technical specifications were met.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference including interference that may cause undesired operation of the device.