




B/W WIRELESS CAMERA




INSTRUCTION MANUAL




Front View



Rear View



Up View



Characteristics:

- * Super high resolution and sensitivity
- * Low consumption and excellent stabilization
- * Wireless Audio/Video out
- * 2.4GHz band, four different bands can be selected
- * Fit for short distance wireless security system of inside and outside

Specifications:

Channel	CH1	CH2	CH3	CH4
Frequency	2413MHz	2432MHz	2451MHz	2470MHz
Impedance	75 Ω			
Video out	1Vp-p			
Audio out	2Vp-p Max			
Voltage	15V/300mA			

Installation:

- 1) To install mounting bracket in the place you want with screw, then fix camera and mounting bracket;
- 2) Camera and mounting bracket can be turned freely (360 ° up and down, left and right) to adjust supervising direction;
- 3) Adjusting screw to adjust tightness of turn direction;
- 4) To install the antenna in the clockwise direction into the " ANT " socket on back of the camera;
- 5) Use DC 15V/300mA adapter to supply the camera;
- 6) This camera should work with the wireless receiving monitor. Any one of " wireless channel select button " of the monitor can be selected, and the selected button should be adjusted to the position of " ON ", the channel of this camera also should be set to the corresponding channel. If want to receive more than two channel-signal, remember the selected buttons of the monitor and the camera should be set corresponding, then picture will switch in each four seconds

Notice:

- 1) To protect camera do not expose to excessive dust or humidity
- 2) Do not place camera in a location subject to direct sunlight or high light
- 3) Make sure the power to the television or monitor is turned off and the power supply
- 4) The bracket for the camera can be selected as you like

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.