


User guide


English
Language
Language
Language

Stereo Streaming Bluetooth™ Headset HBH-IS800



Note: Due to electronic components one of the earplugs can feel a bit warmer than the other.

Note: Due to electronic components one of the earplugs can feel a bit warmer than the other.




First time use: Charge approximately 8 hours.
First time use: Charge approximately 8 hours.

3



4



Red/green indicator light

Turning on and off
Green - Good battery level.
Red - Low battery level.

Normal use

Flashing green - The headset is on.
Flashing red - Low battery.

Pairing

Flashing red/green - Pairing is ongoing.

Charging

Steady red - Charging is ongoing.
Steady green - Charging is ready.

White indicator light

Steady light - A call is ongoing.
Flashing - Pairing is ongoing.

Red/green indicator light

Turning on and off
Green - Good battery level.
Red - Low battery level.

Normal use

Flashing green - The headset is on.
Flashing red - Low battery.

Pairing

Flashing red/green - Pairing is ongoing.

Charging

Steady red - Charging is ongoing.
Steady green - Charging is ready.

White indicator light

Steady light - A call is ongoing.
Flashing - Pairing is ongoing.

English

The Stereo Streaming Bluetooth™ Headset HBH-IS800 lets you stay in control of your incoming and outgoing phone calls. You can enjoy stereo audio from a phone or other Bluetooth device, such as a computer or a portable music player. During calls, the music automatically pauses and starts playing again when the call ends.

For full functionality, your phone or other device should support the following Bluetooth profiles:

- Bluetooth Handsfree
- Bluetooth Headset
- Bluetooth Advanced Audio/Video Distribution
- Bluetooth Audio/Video Remote Control

Charging

Before using the headset for the first time, charge it with the supplied charger for 8 hours, according to picture 2. The headset turns off during charging and switches on automatically when the charger is removed.

For compatible chargers, see picture 3.

Pairing the headset

Before you can use the headset it has to be paired once with your phone. After a successful pairing, the headset will automatically connect to the phone as soon as it is turned on and within range.

Note: The headset turns off if you do not pair it with the phone within 10 minutes.

To pair the headset with the phone

1. Make sure the headset is turned off.
2. Turn on the Bluetooth function in the phone. For instructions, see the phone User guide.
3. Turn on Bluetooth visibility in the phone. This makes the phone visible to other Bluetooth devices.
4. Place the phone within 20 cm (8 inches) from the headset.
5. Press and hold down the action key on the headset for about 5 seconds until the white indicator light starts flashing and the red/green indicator light flashes red and green.
6. Press Yes when Add device? appears in the phone. If required, the passcode is 0000. The white indicator light stops flashing and the red/green indicator light slowly flashes green when successfully paired.

Note: If auto pairing is not supported by your phone, or not successful, follow the first 5 steps above. Then pair the headset with your phone as described in the phone User guide. The passcode is 0000.

Turning on and off

To turn on the headset

- Press and hold down the action key for some seconds until the white indicator light turns on.

To turn off the headset

- Press and hold down the action key until for some seconds the white indicator light disappears.

Adjusting volume

See the phone User guide how to adjust ring volume, speaker volume and music volume.

Calling

To make a call

- Dial the number using the phone keys. The call is automatically activated in the headset.

To end a call

- Press the action key briefly.

To answer a call / a second call

- A beep indicates an incoming call. Briefly press the action key.

To reject a call / a second call

- Press and hold down the action key until you hear a beep.

To redial the last dialled number

- Double-click the action key.

To switch between two calls

- Press and hold down the action key until you hear a beep.

Calling using voice commands

Voice commands can be useful when you are using the headset. For more information on voice commands, and if your phone supports it, see the phone User guide.

To make a call using voice commands

- Press and hold the action key until you hear a beep. Then say the command.

Transferring sound

To transfer the sound from the phone to the headset

- During a call on the phone, press the action key.

To transfer the sound from the headset to the phone

See the phone User guide.

Listening to music

To listen to music

- Start the media player in your phone and select to use the headset.

Briefly press the action key to pause and restart the music.

To move between tracks

- See the phone User guide.

Resetting the headset

Reset the headset if it behaves unexpectedly.

To reset the handsfree

1. Make sure the headset is turned off.
2. Press and hold down the action key on the headset for about 5 seconds until the white indicator light starts flashing and the red/green indicator light flashes red and green.
3. Press and hold the action key on the head set until the headset is completely switched off

Note: After resetting the headset must be paired again before it can be used.

Battery

A battery that has been infrequently used, or a new one, could have reduced capacity. It may need to be recharged a number of times.

When the battery level is too low you hear a low beep. If you do not charge the headset, it automatically turns off within 10 minutes.

Troubleshooting

No connection to the phone

Make sure the headset is charged and within 10 metres (33 feet) of the phone with no solid objects in between. Check or redo the Bluetooth settings in the phone. Try to pair the headset again.

Go to www.sonyericsson.com/learnabout for more information on Bluetooth and pairing.

Redial does not work

- Make sure the call list in the phone is not empty.

Voice commands do not work

- Make sure your phone supports voice commands.
- Make sure the voice commands are enabled and recorded in your phone before you start using them.

The music is not played in the headset

- Make sure your phone or other device is paired with the headset. You may have to restart the media player and select to use the headset.
- Make sure your phone supports the Bluetooth Advanced Audio/Video Distribution profile.

The music volume cannot be changed

- Some mobiles do not support remote volume control. Please check the support website for downloading the additional software.

The headset is automatically turned off

- The battery level is too low. You hear a low beep approximately 10 minutes before the headset turns off. Charge the battery.
- The headset turns off if you do not pair it with the phone within 10 minutes.

Unexpected behaviour

- Reset the headset.

Note: Removing the label from the head set might void the warranty.

Language 2

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Any change or modification not expressly approved by Sony Ericsson may void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Statement

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Declaration of conformity for HBH-IS800

We, Sony Ericsson Mobile Communications AB of Nya Vattentorget SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type DDA-0002019

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards EN 300 328:V1.7.1, EN 301 489-7:V1.3.1, EN 301 489-17:V1.2.1 and EN 60950-1:2006 following the provisions of Radio Equipment and Telecommunication Equipment directive 1999/5/EC.

Lund, July 2008

Jacob Sten, Head of Product Business Unit Accessories
We fulfil the R&TTE Directive.
We fulfil the R&TTE Directive.

Sony Ericsson Mobile Communications AB
SE-221 88 Lund, Sweden
1212-5714.1
Printed in XXXXX


Stereo Streaming
Bluetooth™ Headset HBH-IS800



User guide
User guide
User guide
User guide


Sony Ericsson HBH-IS800
This User guide is published by Sony Ericsson Mobile Communications AB, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide. All rights reserved.
©Sony Ericsson Mobile Communications AB, 2007
Publication number: 1212-5714.1
Some of the services in this User guide are not supported by all networks. This also applies to the GSM International Emergency Number 112. Contact your network operator or service provider if you are in doubt whether you can use a particular service.
The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license.
Sony are trademarks or registered trademarks of Sony Corporation. The Liquid Identity logo is a trademark or registered trademark of Sony Ericsson Mobile Communications AB.
Ericsson is a trademark or registered trademark of Telefonaktiebolaget LM Ericsson.

This product is leadfree and halogenfree.




Note: Due to electronic components one of the earplugs can feel a bit warmer than the other.

Note: Due to electronic components one of the earplugs can feel a bit warmer than the other.



First time use: Charge approximately 8 hours.
First time use: Charge approximately 8 hours.

Language 3



Red/green indicator light
Turning on and off
Green - Good battery level.
Red - Low battery level.

Normal use
Flashing green - The headset is on.
Flashing red - Low battery.

Pairing
Flashing red/green - Pairing is ongoing.

Charging
Steady red - Charging is ongoing.
Steady green - Charging is ready.

White indicator light
Steady light - A call is ongoing.
Flashing - Pairing is ongoing.

Red/green indicator light
Turning on and off
Green - Good battery level.
Red - Low battery level.

Normal use
Flashing green - The headset is on.
Flashing red - Low battery.

Pairing
Flashing red/green - Pairing is ongoing.

Charging
Steady red - Charging is ongoing.
Steady green - Charging is ready.

White indicator light
Steady light - A call is ongoing.
Flashing - Pairing is ongoing.

Language 4