

1. Turn on the computer.
2. Via USB connect the INTERNET SOUNDS TRANSMITTER
3. Set the FM transmitting frequency within 90-106 MHz by setting the adjustment device which can be accessed via botto of the unit.