


56RF-TR-M18 and 56RF-TR-M30

Detail Main_PCB

Please refer to "Theory of Operation_Structure" for antenna position.



56RF-TR-M30
Detail Antenna_PCB

Please refer to "Theory of Operation_Structure" for antenna position.

M30 Antenna

