







# MagicBand



The MagicBand is two different sized bands in one and can be sized to fit most Guests.

For smaller sizes, push the inner band away from the outer band by using a thumb or index finger. Peel the MagicBand swiftly for best results.

Make sure the MagicBand is fitted securely against your wrist facing up.

Under adult supervision the MagicBand icon can be removed with the help of a small screw driver. Do not over-tighten the screws when replacing the MagicBand icon.



Designed in the USA

FCC Compliance Information: This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: 1. The device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation. Note: Changes or modifications not expressly approved by Disney could void the user's authority to operate the equipment.

©Disney