

External Photographs of the Equipment Under Test
EXTERNAL FRONT ANGLE 1



BV01B-Q4601-EFA1

EXTERNAL FRONT ANGLE 2



BV01B-Q4601-ESA2

EXTERNAL SIDE ANGLE



BV01B-Q4601-ESA3

EXTERNAL TOP



BV01B-Q4601-ET4

EXTERNAL BOTTOM



BV01B-Q4601-EB5