


MANUAL

A. REMOTE CONTROLLER

1. See the illustration, fit on the antenna correctly.
2. A couple of remote rod symmetrically stay in the Controller, indicating the following actions respectively.
Left side: forward pulls means go forward, backward pulls means draw back;
Right side: towards the left means left turn, towards the right means right turn.
3. Two grain 1.5V AA batteries are using. See the illustration showing the battery installation, pay attention to the battery polarity.




1. Power Light	2. Forward
3. Backward	4. Antenna
5. Fit on the antenna correctly	
6. Right turn	7. Left turn
8. Take off battery cover, two grain 1.5V AA batteries are needed	

B. TOY CAR BATTERY INSTALLATION INSTRUCTION

1. Take off the battery cover.
2. Four grain 1.5V AA batteries are using.
3. See the illustration showing the battery installation, pay attention to the battery polarity.
4. Turnoff the power on the bottom of the car after finish using. Take out the batteries if the car is not using for a long time.

The Toy Car can turn over up and down 360°, adopt dreaming seven colored lanterns and musical. At the same time, the front wheel can rotating 360°, charming model, make you fondle admiringly.



C. BATTERY CAUTIONS

1. Four grain 1.5V AA battery will be used in the Toy Car, but two in the Remote Controller.
2. Don't charge non-rechargeable batteries.
3. Don't mix new and old batteries or various kinds of batteries.
4. Take off the low batteries in time. Don't disassemble the bad batteries, keep away from fire or water to avoid accidents.

D. MAINTANENCE

Electronic elements, keep away from water and moisture environments. Clean with dry cloth.

E. WARNING

Small parts, not for children under 6 years.

Please read the instructions above carefully before using.

This manual contains important information, please keep carefully.