## 1. Unit Closed:



DSC07236 (EUT Front)



DSC07242 (Back EUT)



DSC07239 (EUT indicating the type of plugs

## 2. Unit opened:



DSC07230 (EUT when opened)

## A. Top portion:




SC07233 (EUT when opened top portion)




IMG\_0657 (Board B) [bottom view of key pad board]



IMG\_0656 (Number Pad) [top view of key pad board]



IMG\_0655 (Board A) [bottom view of RF board]



\* IMG\_0679 (Board A) [top view of RF board]



IMG\_0663 Antenna Board [bottom view of antenna board with ferrite]



IMG\_0662 Antenna Board [ top view of antenna board]



IMG\_0658 (LCD Display) [top view of RF board and antenna board ]

## B. Bottom portion:



DSC07231 (EUT when opened bottom portion)



IMG\_0647 (Board C Front) [top view of main board]



IMG\_0648 (Board C Back) [bottom view of main board]