


PM1350W Installation Instructions

Notes: Please visit our official website www.panstudios.com.cn to obtain usage instructions.


1. Accessories

- a. PM1350PW
- b. RC556p Remote Control
- c. Power Adapter
- d. HDMI Cable
- e. Audio & Video Cable
- f. Installation Instructions



2. Extra Devices

- g. TV**
- h. Removable Hard Disk**
- i. USB Disk**
- j. Net Cable**




This product only provides hardware support for network functions, all related services and network functions are dependent on Internet sources. Our company does not bear any responsibility for Internet content of genuine or the contents of Internet services, or for the losses caused by the legality, stability, stop or turnoff of Internet sources. The change of Internet contents is not included in the functional change of this product, nor can it be used as a reason for the product features missing.


3. Installation

3.1: PM1350PW-HDMI Output


3.1.1 HDMI connected with TV



3.1.2 Power Adap




3.1.3 Completion Presentation of HDMI Connection




3.2: Audio & Video Signal Output


3.2.1 Connection of AV Cable and TV



3.2.2 Power Adapter Connection



3.2.3 Completion Presentation of AV wire



Notes: Please do not put HD Media Player next to high-temperature equipments, vases or devices with water.

4. Other Installation Methods

4.1: Local Play

4.1.1 USB Disk/ Removable Hard Disk Connected to PM1250W



4.2: Net Play

4.2.1 Wired Connection



Notes: Connected with WIFI LAN, not with ADSL straightly.

Notes: More than 2M (measured) broadband Internet connection is available, it is recommended to use ADSL 4M.

4.2.2 Wireless WIFI Connection

A. Press Remote Control Power, HD Media Player



B. Net set, select wireless net --> View available wireless net, press Confirm & select Connect



PM1350W Installation Instructions V: 1.0a

C. Input the password of wireless router user set up, press Return key on remote control. Enter security and select the same encryption with router based on the router encryption. Press remote control Button key to Confirm and then press Confirm to work on wireless configuration connection.




D. WIFI Successfully Connected




4.3: Media Soundbar Connection

4.3.1 Connect HD Media Player AV OUT to Media Soundbar AV IN



Notes: Do not connect the yellow wire when AV wire is connected to Media Sounder.

5: Remote Control Installation with Battery



FCC Statement NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device must not be co-located or operating in conjunction with any other antenna or transmitter.
This device must be installed and operated with a minimum distance of 20 cm between the radiator include its antenna and user body.