

User Manual

Revision	Remarks	Date
1.0	Release	2011-12-16

4. TO activate system

Initially, the battery is not full charged and it may be in protected or inactive mode. It needs to activate system and charge:

To put the speaker on a stable surface.


To plug USB cable to 3.5 DC Jack interface of speaker's power supply

It will charge for speaker after plug USB cable to connect USB with computer's USB for charging.

5. How to use

Power on/off (Red/Green LED)


Turn on the Speaker by on/off- switch on lower right side.



Function key (Bluetooth logo button)

Hold the function key about 5 seconds, the Red/Blue indicator LED on the front will flash. Then the Bluetooth module starts working. And pairing with your mobile can begin

After inputting the password “0000” and choose for connecting “XXXXXX”, it means finished connecting when the blue indicator turns to shining.



P.S. some new devices will finish BT pairing automatically, no need password.

Important notice: Above is the typical hands-free Bluetooth pairing instructions, and it may vary with different mobile phone models. For more information, please refer to the user manual or contact the mobile phone's manufacturers.


Play music by A2DP:

Support the Advanced Audio specification A2DP. A2DP technology is a new music innovation, which allows wireless transfer between different devices like CD-quality stereo music. Remove stereo music over Bluetooth, cable winding. Therefore, if your phone supports A2DP, you can listen to music through the car stereo. View the following steps:

Play music by mobile phone

To open the phone's music player after paring and connecting.

Press the Bluetooth logo function key to pause music during playing music, and press again to resume.




Important Notice: Some phones need to manually connect A2DP, in this case, you need to manually select the "Play via Bluetooth" (with the difference of phone model. Please refer to the mobile phone user manual for accessing to music through A2DP).

Hands-free calls

To press once for answering call when receiving an incoming call, press again for ending the call during a phone call.

Redial the last calling number, press the key twice swiftly.


**Play music by other audio devices:**

The device has a 3.5 mm audio input plug. It can be achieved from other similar MP3, iPod, CD players and other audio players to transmit audio signals. Only need to connect your audio player with the incidental audio cable simply. At this point the device can be connected to the maximum volume setting, and then use the system to adjust its volume buttons.



Speaker's volume controller

- Press the +, - for volume control



Use battery-powered

If the system is set to 80% volume, a fully charged battery sustainable supply for about 6-8 hours. However, the battery discharge rate is due to the music type and volume setting. Decrease the volume can greatly extend the battery life.

6. Battery indicator


Blinks red when fully charged battery is 25% or less (needs charging)

Battery Protection Mode

Hold the function key will switch the status between standby and working. No need use the main Power switch on the right. Hold the function key about 4S, the LED indicator on front will go out, and the speak is automatically in standby mode. Continue in the same way to resume the working status.

But if the system not use longer than 50 days, the system will enter the battery protection mode to protect the battery power. To resume working status, please turn off the main power switch on the right, and connect to a computer or any other standard USB port to

activate it. (see the picture as below). When stocking it for a long time without use, please turn off the main power switch on the right, Then the system can not enter the battery protection mode.




Remark: turn off the power if no use for a long time,


7. Charging the battery

1. To charge the Speaker, connect the DC plug on the included USB Power Cable to the Power input located on the right of the speaker.
2. Connect the USB end to a powered USB port.

Recommended charging time is 3.5 hours. The red LED light will keep on while the speaker is being charged.



Red LEDBattery in charging
Green LEDFull charge



FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.