

EyE Audio

Neodymium speaker
55mm / 10W

Bluetooth 4.1



Single



Paired



Tip : If bluetooth is failed to link:
1) Delete "EyE-Axx yantouch" from your phone, and pair again.
2) Off and on to reset EyE-A, and pair again.



~ 10m / 30'



For most cases, distance should exceed 10m.

Accessories



Micro USB cable

Charging


Green light : 100%, red light : charging



Power stand on



Power stand off



Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



EyE Audio

YTL120G / YTL120R

钕磁鐵喇叭
55mm / 10W



藍芽 4.1

鋰電池 2600mAh

低音共振管
音源插孔 (3.5mm)
Micro USB 充電孔
電源開關 / 支架

單機



配件

充電方式

綠色燈號：100%，紅色燈號：充電中



Micro USB 線



電源腳架開起



電源腳架關閉

一對

1.

打開第一台 EyE-A



2.

打開另一台 EyE-A



3. 自動配對 (~30s)

提示：若自動配對時間超過 60s，請將 EyE-A 重新開關機後，再配對

配對成功

4.

Left channel
提示音



主機



副機

與主機配對

5.



手機設定

藍芽 → 主機 ID : EyE-Axx yantouch

已連接

6.

喇叭

主機 - 左聲道

副機 - 右聲道




大多數情況下，兩顆喇叭之間的距離可以超過 5m
但是，在周遭較多無線設備的環境下，連線距離可能受到影響

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。



Tma : 35°C

Set up:



Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

注意

如果電池更換不當，會有爆炸的危險。只能更換相同或同等類型。

電池（或電池安裝），不得曝曬過多的熱能，如陽光，火。

