

802.11be-EHT160 – Ant 2

Channel 143 (6665MHz)

The Reference Level




The Mask Data



802.11be-EHT320 – Ant 2

Channel 31 (6105MHz)

The Reference Level




The Mask Data



802.11be-EHT320 – Ant 2

Channel 63 (6265MHz)

The Reference Level



The Mask Data



802.11ax-HE 20 – Ant 3

Channel 1 (5955MHz)

The Reference Level




The Mask Data



Channel 49 (6195MHz)

The Reference Level



The Mask Data



Channel 93 (6415MHz)

The Reference Level



The Mask Data



802.11ax-HE 20 – Ant 3

Channel 117 (6535MHz)

The Reference Level



The Mask Data



Channel 153 (6715MHz)

The Reference Level



The Mask Data



Channel 181 (6855MHz)

The Reference Level




The Mask Data



802.11ax-HE40 – Ant 3

Channel 3 (5965MHz)

The Reference Level



The Mask Data



Channel 51 (6205MHz)

The Reference Level



The Mask Data



Channel 91 (6405MHz)

The Reference Level




The Mask Data



802.11ax-HE40 – Ant 3

Channel 123 (6565MHz)

The Reference Level



The Mask Data




Channel 147 (6685MHz)

The Reference Level



The Mask Data



Channel 179 (6845MHz)

The Reference Level




The Mask Data



802.11ax-HE80 – Ant 3

Channel 7 (5985MHz)

The Reference Level



The Mask Data



Channel 55 (6225MHz)

The Reference Level



The Mask Data



Channel 87 (6385MHz)

The Reference Level




The Mask Data



802.11ax-HE80 – Ant 3

Channel 135 (6625MHz)

The Reference Level



The Mask Data



Channel 151 (6705MHz)

The Reference Level



The Mask Data



Channel 167 (6785MHz)

The Reference Level



The Mask Data



802.11ax-HE160 – Ant 3

Channel 15 (6025MHz)

The Reference Level



The Mask Data



Channel 47 (6185MHz)

The Reference Level



The Mask Data



Channel 79 (6345MHz)

The Reference Level



The Mask Data



802.11ax-HE160 – Ant 3

Channel 143 (6665MHz)

The Reference Level



The Mask Data



802.11be-EHT20 – Ant 3

Channel 1 (5955MHz)

The Reference Level




The Mask Data



Channel 49 (6195MHz)

The Reference Level



The Mask Data



Channel 93 (6415MHz)

The Reference Level



The Mask Data



802.11be-EHT20 – Ant 3

Channel 117 (6535MHz)

The Reference Level



The Mask Data



Channel 153 (6715MHz)

The Reference Level



The Mask Data



Channel 181 (6855MHz)

The Reference Level



The Mask Data



802.11be-EHT40 – Ant 3

Channel 3 (5965MHz)

The Reference Level



The Mask Data



Channel 51 (6205MHz)

The Reference Level



The Mask Data




Channel 91 (6405MHz)

The Reference Level



The Mask Data



802.11be-EHT40 – Ant 3

Channel 123 (6565MHz)

The Reference Level




The Mask Data




Channel 147 (6685MHz)

The Reference Level



The Mask Data



Channel 179 (6845MHz)

The Reference Level



The Mask Data



802.11be-EHT80 – Ant 3

Channel 7 (5985MHz)

The Reference Level



The Mask Data



Channel 55 (6225MHz)

The Reference Level




The Mask Data



Channel 87 (6385MHz)

The Reference Level



The Mask Data



802.11be-EHT80 – Ant 3

Channel 135 (6625MHz)

The Reference Level



The Mask Data



Channel 151 (6705MHz)

The Reference Level



The Mask Data



Channel 167 (6785MHz)

The Reference Level



The Mask Data

