


CT9 operating guide

If you need to understand the details, Please visit our website: www.hotah.cn

Or stored in the reference on electronic instructions




Turn on/off



Power switch

- Power up the device: Hold down the right power button of the device, which is located at the upper right corner.
- To turn off the device, hold down the button which is located at the top upper right corner until the monitor shows the "OFF" option. Click on the OFF option and click on the "OK" button. The monitor will turn off after a few seconds. To restart the monitor, press the power switch again.

Main menu



Wi-Fi settings



- Open the Applications tab In the main interface, then click "Settings"
- After Choose: "Wireless network" click "Wi-Fi", click on "Wi-Fi settings"
- Click connect to network, that will be can connected, if the network requires a password, enter the correct password in the password bar, WALN shows "Connected."
- Network settings after completion, return to the main interface, then, you can use the network, and can be in the browser's address bar, enter the desired website address..
- Open the webpage, click or sliding webpage, click the link to open the linked page.

Browse the file or folder

- In Desktop state, click the application bar icon, enter into the application field, click into the "resource manager".
- In the file list can be clickable sliding, rolling.
- Click on the required file or folder, can open the file or folder.
- Click the status bar of the back button to return to the level folder.
- Click the Home button on the status bar, you can return to the home page.
- Long press a file or folder, can popup a menu, for example: "Copy, delete, move, paste, rename" and other additional options. If you do not execute the operation, click on the Cancel button. directly




USB connection



- Connect USB line interface, plug in the machine of right side USB interface, the other point is inserted in the computer USB interface connection, drag down the status bar, and then show USB connection status, that will be appear "USB connection", prompting USB connection.
- If successful, your computer will be appear a new removable disk.
- On the computer desktop to open "My Computer", double-click the new removable disk, where the data can be copied, deleted by machine
- Disconnect: Click the bottom left of the screen arrow to the removable disk icon, pop up a small window safe deletion mobile disk.

Install / uninstall software

- CT9 operating system default for Android 4.0 version, install the software required to process the format is*. Apk format.
- CT9 supports many popular third-party application software formats
- CT9 can be installed or uninstalled you need software.
- To install an application, the need to*. Apk format copied to your CT9, then open "resource manager", click to install*. Apk file.
- Installed application, will appear in the application bar.
- If want to installed software, click "setting" enter into "application process" bar, then Click:"application", click on the software you want to ininstall. then click uninstall.



Other application

Multimedia

- CT9 can support HD video playback, photo viewing, and music.
- Firstly. need to play music, video, photos copy to the CT9.
- Click the application icon, after enter, click on the corresponding icon, such as "video" "picture" "music" into the corresponding interface.
- Click the file of play, it can be play file.

Filming

- CT9 have camera equipment both front and back, they can both photograph and taking pictures.
- Click the application bar, click on the "camera" icon, you can practice taking pictures and filming video, and in the corresponding function menu set the video clarity and screen size.



Hardware configuration	
Main Frenquency	ARM Cortex™ -8 1GHZ
CPU	RK2918
Inner memory	1G DDR3
Screen	9.7 inch 1024×768
	5 points capacitive touch panel
Memory	8GB、16GB、32GB
Camera	30W+200W camera
WiFi	Wi-Fi 8188
Volumn	D class built-in speakers
Expansion card	TF card, Support maximum 32GB TF card
Battery	140*140*3.6 (mm)
Data port	2 USB 2.0 OTG high-speed interface,Support for external 3G, HDMI

Operating system	
Operating system	Google Android 4.0
SNR	≥92db
Outlook specification	
Product Dimension L×W×H(mm)	243.6*190.6*10.5 (mm)

Function feature	
Mobile memory	It can be used as movable hardware Disk
Input	Android keyboard、Google Pinyin input method
Audio	MP3、WMA、OGG、APE、FLAC、AAC、WAV
Video	Max support 1080P of H.264、VP8、RV、WMV、AVS、H.263、MPEG4 etc and live video of Youtube、720P、HTML5、Flash10.3 etc
Picture	Support for JPG, BMP, PNG and other image formats browsing and support the rotating / slide / picture zoom function
Other applications	2D/3D graphics processor, Support OpenGL ES 2.0 and Open VG
	Webpage browsing、Chat online、E-mail、E-book、Explorer
	Clock、Alarm clock、Calculator、Recording
Audio mode	Normal、Pop、Rock、Classical、Jazz、Heavy bass、User-defined
Language	Multi—language support (optional)
Repeat mode	Single song once、single repeated、all once、all repeated、demo
Recording	microphone support; support MP3/WAV format recording

* Note: Use MicroTF (SD) card, if you want to pull out the TF card, safe operation is the select Settings -> memory -> unload TF card.

Disclaimer Note: product appearance, technical parameter, function, price, please take the actual product and the product specification, nameplate shall prevail, as a result of technology to update the changes, without notice.

Federal Communications Commission (FCC) Statement



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 68 of the FCC Rules.

This device should be installed and operated with a minimum distance of 20 cm between the antenna and all persons.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: "Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."