

eTab Device User Manual

7 inch and 5 inch devices

Version 1.1

Document Number: TD0025

Approval Date: 10-04-2012

Author: Veronica M. Villareal

Document Owners

Veronica M. Villareal

Manager – Office, QA, Menu Building, & Compliance

eTab International, Inc.

eTab International, Inc. 

Confidential Information

The information contained in this document is eTab International, Inc. confidential and has been prepared to establish internal policies and procedures. Distribution of this document outside of eTab International Inc. is strictly prohibited. Do not copy or distribute without the permission of the Chief Executive Officer.

Revision Log

Version	Description of Change	Author	Date
1.0	Initial Release	Veronica M. Villareal	10-04-2012
1.1	Add FCC Statement	Veronica M. Villareal	10-10-2012

Table of Contents

1	FCC Statement	4
2	Introduction	4
2.1	Turn on Devices	5
2.2	Turn off Devices	6
2.3	Change Battery on Devices	7
2.4	General Care Cleaning	8

1 FCC Statement

Any modifications to the unit, unless expressly approved by eTab, could void the user's authority to operate the equipment. *NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.* These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or locate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device has been tested and found to comply with the FCC RF Exposure requirements.

2 Introduction

This document will provide general instruction on how to operate the eTab 7 inch and 5 inch devices as follows:

- Turn on devices
- Change battery on devices
- General care and cleaning

Note: Instructions provided in this user guide apply to both the 7 inch and 5 inch eTab devices.

2.1 Turn on Devices

Follow these instructions for turning on the 5 and 7 inch devices:

1. Use the end of a paper clip for powering on the device.



2. Insert the end of the paper clip into the small hole in the back of the device; hold until you feel the power button click.



3. Hold the power button down until the device turns on; then release the paper clip.



2.2 Turn off Devices

Follow these instructions for turning on the 5 and 7 inch devices:


1. Use the end of a paper clip for powering off the device.



2. Insert the end of the paper clip into the small hole in the back of the device; hold until you feel the power button click.



3. Hold the power button down until the device turns off; then release the paper clip.



2.3 Change Battery on Devices

Follow these instructions for changing the battery on the 5 and 7 inch devices:

1. On the back of the device, pull down the battery release latch.



2. While pulling down the release latch, slide the battery out of the device.



3. Slide a fully charged battery into the battery slot until the latch clicks.



2.4 General Care Cleaning

To clean the devices, use a damp soft cloth to wipe the front and back of the devices. *Note: Do not use any harsh or abrasive cleaners.*

