




User's Manual

Model No. : RF TRANSMITTER
Test Report No.:BWS-02-WF-0001

APPENDIX 4

User's Manual



FM Transmitter

* Function

It helps you enjoy stereo music of high quality without any connected line by transmitting MP GIO's sound source by FM frequency in a car.

* Description of each part

- # 10 . FM transmitter frequency option button
- # 11 . LED lamp
- # 12 . Lock

* Operation method

- ① Turn player ON.
- ② Combine FM Transmitter.
(then, no.11(lamp) blinks once)
- ③ Tune in the radio frequency to 88.1 Mhz.

* Press #10, if you want to change reception frequency. Then, it is changed into 88.1Mhz → 88.5Mhz → 88.9Mhz → 89.3Mhz. And #11 lamp displays station by blinking 4 times.



FCC Compliance Statements

NOTE : This equipment has been tested and found to comply with the limits for a FCC Subpart C device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates ,uses and can radiate radio frequency energy and ,if not installed and used in accordance with the instruction , may cause harmful interference to radio communication. However , there is no guarantee that interference will not occur in a particular installation.

If this equipment dose harmful interference to radio or television reception ,which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Warning : Your are cautioned that any change or modifications to the equipment not prissily approved by the party responsible for compliance could void your authority to operate such equipment.

NOTE : This unit was tested with shielded cables on the peripheral device .
Shield cables must be used with the unit to insure compliance.



User's Manual

Model No. : RF TRANSMITTER
Test Report No.:BWS-02-WF-0001