


## 6. SETUP PHOTOS

### DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP



DFS SIDE PHOTO (EUT)



DFS FRONT PHOTO (CLIENT MODE SETUP)



DFS FRONT PHOTO (CLIENT-TO-CLIENT COMMUNICATIONS  
MODE SETUP)



**END OF REPORT**