

2. Press the Menu button to display "Preview" and "Setup". Press the PLAY/OK button on "Setup".



3. When the Picture Taking Settings screen appears, move to the field you want to set, and select the desired setting for that field using the left/right button.



- Mode: Select Movie or Still mode.
- Speed: In movie mode, you can select the rate of picture taking in units of frames per second.
- The maximum frame rate is 5 frames/sec for 320x240 resolution and 2.5 frames/sec for 640x480 resolution.
- Size: Select the picture taking resolution, either 640x480 or 320x240.
- Sticker: Select a “sticker frame” – a frame that will be put on your pictures at the time of capture.
- You can download new sticker frames using the Magic Sync software.

Using PIMS

PIMS Mode

- You can also manage your PIM data and synchronize with your PC using the Magic Diary software.

Display

Features



Address: Records some personal information including name, phone number, address, and birthday.

Anniversary: Set reminders for important days to remember.

Schedule: Maintain notes for appointments, with viewing by day, week, or month.

Memo: Store short text messages for reference or reminders.

Profile: Store your business card and beam it to colleagues and friends.

Game: Enjoys a game.

World Time: Find the time anywhere in the world from this stylish map application.

Calculator: A simple four-function calculator is provided for your convenience.

Changing a desktop

Refer to Player mode (page ?).

Address book

1. There are 7 selections as following:



- New – Create a new address book record.
- Group – View records assigned to a particular group.
- Name – Search for a record by name.
- Beam – Send the selected records to another MKIVKI via infrared.
- Delete – Delete selected records.
- Select All – Select all records.
- Deselect – Cancel the current selection.


Adding an address

- You can save up to 300 addresses in the address book.


1. Select 'Address' icon, and press the PLAY/OK button to display an address list.



2. Press the 'Menu' button, and select 'New'.



3. In **Information input window**, select the characters you wish to input using the 'up/down' button and press the 'PLAY/OK' button.



- Use left/right button to scroll the text.

4. In **Character Input window**, select the character you wish to input and press the 'PLAY/OK' button.



Input Method (Hot Keys)


Delete : select button + Up button

Space : select button + Down button

`<- : Select button + Left button`


-> : Select button + Right button

5. To change the type of character to input, select a character by pressing the 'Menu' button.




■ You can also change the type of character using 'Vol' button on the left side of the terminal.

6. When you finish character input, use 'Done' in the menu or the 'BACK' button to complete.




7. To select an Avatar, select the desired avatar from the choices offered by pressing the PLAY/OK button.




- For the items of cellular phone, home, office, Email, note, etc., refer to How to input character and How to save the information.

8. Specify the birthday and group using the left and right buttons.



- Year of birth is limited to dates between 1910 and 2010.
- The group is limited to the provided choices: All, Family, School, Club, Work and Etc.

9. After entering each item, save the information by using 'Save' in the menu or the 'BACK' button.




Modifying an address

1. Select the name to modify in the list and press the PLAY/OK button.



2. Select the item to modify, and press the PLAY/OK button.



3. Please modify in the same way as 'Adding an address'.

4. Save the information after modifying. (refer to page ?)




Deleting an address

1. Select a name to delete from the list, press 'Menu' button, and select 'Delete'.




2. In the message window, select 'Yes' and press the PLAY/OK button.



- To select multiple files, move to each desired file in the list using the up/down button and press the SEL button to select each file. Press the SEL button again to deselect a list entry.

Transferring an address

1. Select an item to transfer from the list, and press the PLAY/OK button.




Displaying a Group

1. Press the 'Menu' button on the list, select Group, and press the PLAY/OK button.



2. Select the desired group, and press the PLAY/OK button.



3. The list of records assigned to the selected group will be shown.



Searching for a Record


1. Press 'Menu' button on the list, select Search, and press the 'PLAY/OK' button.



2. Type a text string to search for. For example, if you type in the full string “Kelly”, you will find the record corresponding to the name “Kelly”; if you type only the letter “K”, the search will find all records whose name has “K”.



3. Press Menu button and select Search on the list or press Back button to search.



4. The results of the search are displayed in the list screen. If no records were found, a message window is displayed.




Adding an anniversary

- You can save up to 100 anniversaries.

1. To see the list of anniversaries, select 'ANNIV' icon and press the PLAY/OK button.



2. Press the 'Menu' button, select 'New', and press the PLAY/OK button.



3. How to input and save is same as in 'Adding an address'. (Refer to page ?)

Modifying an anniversary

1. How to modify is same as in 'Modifying an address' (Refer to page ?).



Deleting an anniversary


1. How to delete is same as in 'Deleting an address' (Refer to ?~page ?).




Using the Schedule menu function

1. The schedule menu has four entries:

- New – Creates a new schedule entry.




- Daily – Displays the day view for the schedule.



- You can switch to the daily view directly from the Calendar view by selecting a date and pressing the "PLAY/OK" button.
- You can scroll forward and backwards to the previous and next day by pressing the left/right buttons.


- Weekly – Displays the weekly view for the schedule.

- The first schedule for each day is shown in the weekly schedule view.
- You can scroll through weeks by pressing the left and right button.



- Calendar – Displays the monthly view for the schedule.

To view detailed schedule entries, please use the daily or weekly view.



- You can change to the next or previous month by using the volume up/down buttons.

Adding a schedule


- The calendar can store up to 750 schedule entries.

- To see the calendar, select 'Schedule' icon and press the 'PLAY/OK' button. To view Schedule list, select the date in the calendar and press the 'PLAY/OK' button.



- Days that have schedule entries are highlighted in yellow.

2. Press the 'Menu' button, select 'New', and press the PLAY/OK button.



3. How to input and save is same as in 'Adding an address (refer to page ?)'.


Modifying a schedule

1. How to modify is same as in 'Modifying an address' (refer to page ?).



Deleting a schedule


1. How to delete is same as in 'Deleting an address' (Refer to ?~page ?).




Adding a memo

- The memo function can store up to 100 entries.

- To see the memo list, select 'Memo' icon and press the 'PLAY/OK' button.




- Press the 'Menu' button, select 'New', and press the 'PLAY/OK' button.



3. How to input and save is same as in 'Adding an address (Refer to page ?)'.

Modifying a memo

1. How to modify is same as in 'Modifying an address' (Refer to page ?).




Deleting a memo

1. How to delete is same as in 'Deleting an address' (Refer to ?~page ?).



Setting up your profile


1. Select 'Profile' icon, and press the 'PLAY/OK' button.



2. How to input and save is same as in 'Adding an address (Refer to page ?)'.

Game

1. Select 'Game' icon, and press the 'PLAY/OK' button.




2. The game menu has two selections: "Start" and "Exit".

3. Press "Start" to begin the game.

▲: Pause ▼: Down ◀: Left ▶: Right


(PLAY/OK): Change the shape Select: Down fast




4. To end the game, press the “BACK” button, or press “Menu” button and select “Exit”.

Using the World Time

1. Select ‘World Time’ icon, and press the ‘PLAY/OK’ button.



2. The time and date is displayed by city on the top, and the time zone for World Time is displayed with the red bar on the bottom.



- The user time zone could be changed in “Control” in the Player mode.