



8.4 Setup Photograph:



9kHz-30MHz





30-1000MHz



1-18 GHz



18-40 GHz



Above 40GHz

